






OM-252 624G


2013-04

Processes

 MIG (GMAW) Welding
Flux Cored (FCAW) Welding

 Stick (SMAW) Welding

 TIG (GTAW) Welding


 Air Carbon Arc (CAC-A)
Cutting and Gouging

Description



Engine Driven Welding Generator

Big Blue[®] 700 Duo Pro[®] Big Blue[®] 700X Duo Pro[®]



OWNER'S MANUAL

File: Engine Drive 



Visit our website at
www.MillerWelds.com

From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite.

We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide the exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001 Quality System Standard.

Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual specification sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at www.MillerWelds.com on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.



TABLE OF CONTENTS

| | |
|---------------------------------------------------------------------------------------------------------|-----------|
| SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING | 1 |
| 1-1. Symbol Usage | 1 |
| 1-2. Arc Welding Hazards | 1 |
| 1-3. Engine Hazards | 3 |
| 1-4. Compressed Air Hazards | 3 |
| 1-5. Additional Symbols For Installation, Operation, And Maintenance | 4 |
| 1-6. California Proposition 65 Warnings | 6 |
| 1-7. Principal Safety Standards | 6 |
| 1-8. EMF Information | 6 |
| SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION | 7 |
| 2-1. Signification des symboles | 7 |
| 2-2. Dangers relatifs au soudage à l'arc | 7 |
| 2-3. Dangers existant en relation avec le moteur | 9 |
| 2-4. Dangers liés à l'air comprimé | 10 |
| 2-5. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance | 11 |
| 2-6. Proposition californienne 65 Avertissements | 13 |
| 2-7. Principales normes de sécurité | 13 |
| 2-8. Informations relatives aux CEM | 13 |
| SECTION 3 – DEFINITIONS | 14 |
| 3-1. Additional Safety Symbols And Definitions | 14 |
| 3-2. Miscellaneous Symbols And Definitions | 17 |
| SECTION 4 – SPECIFICATIONS | 18 |
| 4-1. Weld, Power, And Engine Specifications | 18 |
| 4-2. Environmental Specifications | 18 |
| 4-3. Dimensions, Weights, And Operating Angles | 19 |
| 4-4. Volt-Ampere Curves | 20 |
| 4-5. Volt-Ampere Curves For Paralleled Output | 21 |
| 4-6. Fuel Consumption | 22 |
| 4-7. Duty Cycle And Overheating | 22 |
| 4-8. AC Generator Power Curves | 23 |
| SECTION 5 – INSTALLATION | 25 |
| 5-1. Serial Number And Rating Label Locations | 25 |
| 5-2. Installing Welding Generator | 25 |
| 5-3. Mounting Welding Generator | 26 |
| 5-4. Grounding Generator To Truck Or Trailer Frame | 27 |
| 5-5. Installing Exhaust Pipe | 27 |
| 5-6. Connecting The Battery | 28 |
| 5-7. Engine Prestart Checks | 29 |
| 5-8. Connecting To Weld Output Terminals | 30 |
| 5-9. Making Dual Operator CC Weld Connections w/ Separate Work Cables | 31 |
| 5-10. Making Dual Operator Mode CC Weld Connections w/ Common Work Cable | 32 |
| 5-11. Making Dual Operator CV Weld Connections w/ Separate Work Cables | 33 |
| 5-12. Making Dual Operator CV Weld Connections w/ Common Work Cable | 34 |
| 5-13. Making Dual Operator CC And CV Weld Connections w/ Separate Work Cables | 35 |
| 5-14. Making Dual Operator CC And CV Weld Connections w/ Common Work Cable | 36 |
| 5-15. Making Single Operator CC Weld Connections | 37 |
| 5-16. Weld Output Terminals And Selecting Cable Sizes* | 38 |
| 5-17. Connecting To Remote 14 Receptacle | 39 |

TABLE OF CONTENTS

| | |
|------------------------------------------------------------------|-----------|
| SECTION 6 – OPERATING WELDING GENERATOR | 40 |
| 6-1. Front Panel Controls (See Section 6-2) | 40 |
| 6-2. Description Of Front Panel Controls (See Section 6-1) | 41 |
| 6-3. Process/Contactor Switch | 42 |
| 6-4. Arc Control | 43 |
| 6-5. Low Open-Circuit Voltage (VRD) Switch | 44 |
| 6-6. Stick Start Procedure – Scratch Start Technique | 44 |
| 6-7. Lift-Arc™ TIG With Auto-Stop™ | 45 |
| 6-8. Remote Voltage/Amperage Control | 46 |
| 6-9. Oil Pan Heater | 47 |
| 6-10. Fuel/Hour Gauge Descriptions | 48 |
| SECTION 7 – OPERATING AUXILIARY EQUIPMENT | 49 |
| 7-1. North American Auxiliary Power Receptacles | 49 |
| 7-2. Export Auxiliary Power Receptacles | 50 |
| 7-3. GFCI Receptacle Information, Resetting And Testing | 51 |
| SECTION 8 – MAINTENANCE & TROUBLESHOOTING | 52 |
| 8-1. Maintenance Label | 52 |
| 8-2. Routine Maintenance | 53 |
| 8-3. Checking Generator Brushes | 54 |
| 8-4. Servicing Air Cleaner | 55 |
| 8-5. Adjusting Engine Speed | 56 |
| 8-6. Servicing Fuel And Lubrication Systems | 57 |
| 8-7. Overload Protection | 58 |
| 8-8. Voltmeter/Ammeter Help Displays | 59 |
| 8-9. Troubleshooting | 60 |
| SECTION 9 – ELECTRICAL DIAGRAMS | 64 |
| SECTION 10 – RUN-IN PROCEDURE | 68 |
| 10-1. Wetstacking | 68 |
| 10-2. Run-In Procedure Using Load Bank | 69 |
| 10-3. Run-In Procedure Using Resistance Grid | 70 |
| SECTION 11 – GENERATOR POWER GUIDELINES | 71 |
| SECTION 12 – PARTS LIST | 78 |
| WARRANTY | |

SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING

rom_2011-10

 **Protect yourself and others from injury — read, follow, and save these important safety precautions and operating instructions.**

1-1. Symbol Usage



DANGER! – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

NOTICE – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards



The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-7. Read and follow all Safety Standards.



Only qualified persons should install, operate, maintain, and repair this unit.



During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install, ground, and operate this equipment according to its Owner's Manual and national, state, and local codes.

- Always verify the supply ground — check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord for damage or bare wiring — replace cord immediately if damaged — bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal. Disconnect cable for process not in use.


SIGNIFICANT DC VOLTAGE exists in inverter power sources AFTER stopping engine.

- Stop engine on inverter and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local forced ventilation at the arc to remove welding fumes and gases.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



BUILDUP OF GAS can injure or kill.

- Shut off compressed gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare, and sparks; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather, heavy cotton, or wool) and foot protection.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.

- Do not weld on containers that have held combustibles, or on closed containers such as tanks, drums, or pipes unless they are properly prepared according to AWS F4.1 and AWS A6.0 (see Safety Standards).
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.



NOISE can damage hearing.


Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



ELECTRIC AND MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices.

- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



CYLINDERS can explode if damaged.

Compressed gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder — explosion will result.
- Use only correct compressed gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

1-3. Engine Hazards



BATTERY EXPLOSION can injure.

- Always wear a face shield, rubber gloves, and protective clothing when working on a battery.
- Stop engine before disconnecting or connecting battery cables, battery charging cables (if applicable), or servicing battery.
- Do not allow tools to cause sparks when working on a battery.
- Do not use welder to charge batteries or jump start vehicles unless the unit has a battery charging feature designed for this purpose.
- Observe correct polarity (+ and -) on batteries.
- Disconnect negative (-) cable first and connect it last.
- Keep sparks, flames, cigarettes, and other ignition sources away from batteries. Batteries produce explosive gases during normal operation and when being charged.
- Follow battery manufacturer's instructions when working on or near a battery.



FUEL can cause fire or explosion.

- Stop engine and let it cool off before checking or adding fuel.
- Do not add fuel while smoking or if unit is near any sparks or open flames.
- Do not overfill tank — allow room for fuel to expand.
- Do not spill fuel. If fuel is spilled, clean up before starting engine.
- Dispose of rags in a fireproof container.
- Always keep nozzle in contact with tank when fueling.



MOVING PARTS can injure.

- Keep away from moving parts such as fans, belts, and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Stop engine before installing or connecting unit.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance and troubleshooting as necessary.
- To prevent accidental starting during servicing, disconnect negative (-) battery cable from battery.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting engine.
- Before working on generator, remove spark plugs or injectors to keep engine from kicking back or starting.
- Block flywheel so that it will not turn while working on generator components.




EXHAUST SPARKS can cause fire.

- Do not let engine exhaust sparks cause fire.
- Use approved engine exhaust spark arrestor in required areas — see applicable codes.




HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.




STEAM AND HOT COOLANT can burn.

- If possible, check coolant level when engine is cold to avoid scalding.
- Always check coolant level at overflow tank, if present on unit, instead of radiator (unless told otherwise in maintenance section or engine manual).
- If the engine is warm, checking is needed, and there is no overflow tank, follow the next two statements.
- Wear safety glasses and gloves and put a rag over radiator cap.
- Turn cap slightly and let pressure escape slowly before completely removing cap.



Using a generator indoors CAN KILL YOU IN MINUTES.

- Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- NEVER use inside a home or garage, EVEN IF doors and windows are open.
- Only use OUTSIDE and far away from windows, doors, and vents.



BATTERY ACID can BURN SKIN and EYES.


- Do not tip battery.
- Replace damaged battery.
- Flush eyes and skin immediately with water.



ENGINE HEAT can cause fire.

- Do not locate unit on, over, or near combustible surfaces or flammables.
- Keep exhaust and exhaust pipes way from flammables.

1-4. Compressed Air Hazards



COMPRESSED AIR EQUIPMENT can injure or kill.

- Incorrect installation or operation of this unit could result in equipment failure and personal injury. Only qualified persons should install, operate, and service this unit according to its Owner's Manual, industry standards, and national, state, and local codes.
- Do not exceed the rated output or capacity of the compressor or any equipment in the compressed air system. Design compressed air system so failure of any component will not put people or property at risk.
- Before working on compressed air system, turn off and lockout/tagout unit, release pressure, and be sure air pressure cannot be accidentally applied.
- Do not work on compressed air system with unit running unless you are a qualified person and following the manufacturer's instructions.
- Do not modify or alter compressor or manufacturer-supplied equipment. Do not disconnect, disable, or override any safety equipment in the compressed air system.
- Use only components and accessories approved by the manufacturer.
- Keep away from potential pinch points or crush points created by equipment connected to the compressed air system.
- Do not work under or around any equipment that is supported only by air pressure. Properly support equipment by mechanical means.




HOT METAL from air arc cutting and gouging can cause fire or explosion.

- Do not cut or gouge near flammables.
- Watch for fire; keep extinguisher nearby.



COMPRESSED AIR can injure or kill.

- Before working on compressed air system, turn off and lockout/tagout unit, release pressure, and be sure air pressure cannot be accidentally applied.
- Relieve pressure before disconnecting or connecting air lines.
- Check compressed air system components and all connections and hoses for damage, leaks, and wear before operating unit.



- Do not direct air stream toward self or others.
- Wear protective equipment such as safety glasses, hearing protection, leather gloves, heavy shirt and trousers, high shoes, and a cap when working on compressed air system.
- Use soapy water or an ultrasonic detector to search for leaks—never use bare hands. Do not use equipment if leaks are found.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting unit.
- If ANY air is injected into the skin or body seek medical help immediately.



BREATHING COMPRESSED AIR can injure or kill.

- Do not use compressed air for breathing.
- Use only for cutting, gouging, and tools.



TRAPPED AIR PRESSURE AND WHIPPING HOSES can injure.

- Release air pressure from tools and system before servicing, adding or changing attachments, or opening compressor oil drain or oil fill cap.



MOVING PARTS can injure.

- Keep away from moving parts such as fans, belts and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.


- Keep hands, hair, loose clothing, and tools away from moving parts.
- Before working on compressed air system, turn off and lockout/tagout unit, release pressure, and be sure air pressure cannot be accidentally applied.
- Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting engine.



HOT PARTS can burn.

- Do not touch hot compressor or air system parts.
- Allow cooling period before working on equipment.

- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



READ INSTRUCTIONS.

- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.

- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.

1-5. Additional Symbols For Installation, Operation, And Maintenance




FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




FALLING EQUIPMENT can injure.

- Use lifting eye to lift unit and properly installed accessories only, NOT gas cylinders. Do not exceed maximum lift eye weight rating (see Specifications).
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.
- Keep equipment (cables and cords) away from moving vehicles when working from an aerial location.
- Follow the guidelines in the Applications Manual for the Revised NIOSH Lifting Equation (Publication No. 94-110) when manually lifting heavy parts or equipment.




OVERHEATING can damage motors.

- Turn off or unplug equipment before starting or stopping engine.
- Do not let low voltage and frequency caused by low engine speed damage electric motors.
- Do not connect 50 or 60 Hertz motors to the 100 Hertz receptacle where applicable.



FLYING SPARKS can injure.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.



MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.



BATTERY CHARGING OUTPUT and BATTERY EXPLOSION can injure.


Battery charging not present on all models.

- Always wear a face shield, rubber gloves, and protective clothing when working on a battery.
- Stop engine before disconnecting or connecting battery cables, battery charging cables (if applicable), or servicing battery.
- Do not allow tools to cause sparks when working on a battery.
- Do not use welder to charge batteries or jump start vehicles unless it has a battery charging feature designed for this purpose.
- Observe correct polarity (+ and -) on batteries.
- Disconnect negative (-) cable first and connect it last.
- Keep sparks, flames, cigarettes, and other ignition sources away from batteries. Batteries produce explosive gases during normal operation and when being charged.
- Follow battery manufacturer's instructions when working on or near a battery.
- Have only qualified persons do battery charging work.
- If battery is being removed from a vehicle for charging, disconnect negative (-) cable first and connect it last. To prevent an arc, make sure all accessories are off.
- Charge lead-acid batteries only. Do not use battery charger to supply power to an extra-low-voltage electrical system or to charge dry cell batteries.
- Do not charge a frozen battery.
- Do not use damaged charging cables.
- Do not charge batteries in a closed area or where ventilation is restricted.
- Do not charge a battery that has loose terminals or one showing damage such as a cracked case or cover.
- Before charging battery, select correct charger voltage to match battery voltage.
- Set battery charging controls to the Off position before connecting to battery. Do not allow battery charging clips to touch each other.
- Keep charging cables away from vehicle hood, door, or moving parts.




WELDING WIRE can injure.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




OVERUSE can cause OVERHEATING.

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.




STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.




TILTING OF TRAILER can injure.

- Use tongue jack or blocks to support weight.
- Properly install welding generator onto trailer according to instructions supplied with trailer.




READ INSTRUCTIONS.

- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.



H.F. RADIATION can cause interference.




- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.




ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as micro-processors, computers, and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.


1-6. California Proposition 65 Warnings

-  **Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)**
-  **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. *Wash hands after handling.***
-  **This product contains chemicals, including lead, known to the state of California to cause cancer, birth defects, or other reproductive harm. *Wash hands after use.***

For Gasoline Engines:

-  **Engine exhaust contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

For Diesel Engines:

-  **Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

1-7. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, is available as a free download from the American Welding Society at <http://www.aws.org> or purchased from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for Welding and Cutting Containers that have Held Combustibles, American Welding Society Standard AWS A6.0, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 14501 George Carter Way, Suite 103, Chantilly, VA 20151 (phone: 703-788-2700, website: www.cganet.com).

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Battery Chargers, CSA Standard C22.2 NO 107.2-01, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite

100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 25 West 43rd Street, New York, NY 10036 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 OSHA Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

Portable Generators Safety Alert, U.S. Consumer Product Safety Commission (CPSC), 4330 East West Highway, Bethesda, MD 20814 (phone: 301-504-7923, website: www.cpsc.gov/cpsc/pub/pubs/portgen.pdf).

Applications Manual for the Revised NIOSH Lifting Equation, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (phone: 1-800-232-4636, website: www.cdc.gov/NIOSH).

1-8. EMF Information

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). Welding current creates an EMF field around the welding circuit and welding equipment. EMF fields may interfere with some medical implants, e.g. pacemakers. Protective measures for persons wearing medical implants have to be taken. For example, restrict access for passers—by or conduct individual risk assessment for welders. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Do not place your body between welding cables. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.

4. Keep head and trunk as far away from the equipment in the welding circuit as possible.
5. Connect work clamp to workpiece as close to the weld as possible.
6. Do not work next to, sit or lean on the welding power source.
7. Do not weld whilst carrying the welding power source or wire feeder.

About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.

SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

fre_rom_2011-10

! Pour écarter les risques de blessure pour vous-même et pour autrui — lire, appliquer et ranger en lieu sûr ces consignes relatives aux précautions de sécurité et au mode opératoire.

2-1. Signification des symboles

! **DANGER!** – Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

! Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

NOTE – Indique des déclarations pas en relation avec des blessures personnelles.

 Indique des instructions spécifiques.



Ce groupe de symboles veut dire Avertissement! Attention! DANGER DE CHOC ELECTRIQUE, PIECES EN MOUVEMENT, et PIECES CHAUDES. Consulter les symboles et les instructions ci-dessous y afférant pour les actions nécessaires afin d'éviter le danger.

2-2. Dangers relatifs au soudage à l'arc

! Les symboles présentés ci-après sont utilisés tout au long du présent manuel pour attirer votre attention et identifier les risques de danger. Lorsque vous voyez un symbole, soyez vigilant et suivez les directives mentionnées afin d'éviter tout danger. Les consignes de sécurité présentées ci-après ne font que résumer l'information contenue dans les normes de sécurité énumérées à la section 1-7. Veuillez lire et respecter toutes ces normes de sécurité.

! L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées.

! Au cours de l'utilisation, tenir toute personne à l'écart et plus particulièrement les enfants.



UN CHOC ÉLECTRIQUE peut tuer.

Un simple contact avec des pièces électriques peut provoquer une électrocution ou des blessures graves. L'électrode et le circuit de soudage sont sous tension dès que l'appareil est sur ON. Le circuit d'entrée et les circuits internes de l'appareil sont également sous tension à ce moment-là. En soudage semi-automatique ou automatique, le fil, le dévidoir, le logement des galets d'entraînement et les pièces métalliques en contact avec le fil de soudage sont sous tension. Des matériels mal installés ou mal mis à la terre présentent un danger.

- Ne jamais toucher les pièces électriques sous tension.
- Porter des gants et des vêtements de protection secs ne comportant pas de trous.
- S'isoler de la pièce et de la terre au moyen de tapis ou d'autres moyens isolants suffisamment grands pour empêcher le contact physique éventuel avec la pièce ou la terre.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- Des précautions de sécurité supplémentaires sont requises dans des environnements à risque comme: les endroits humides ou lorsque l'on porte des vêtements mouillés; sur des structures métalliques au sol, grillages et échafaudages; dans des positions assises, à genoux et allongées; ou quand il y a un risque important de contact accidentel avec la pièce ou le sol. Dans ces cas utiliser les appareils suivants dans l'ordre de préférence: 1) un poste à souder DC semi-automatique de type CV (MIG/MAG), 2) un poste à souder manuel (électrode enrobée) DC, 3) un poste à souder manuel AC avec tension à vide réduite. Dans la plupart des cas, un poste courant continu de type CV est recommandé. Et, ne pas travailler seul!
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installez, mettez à la terre et utilisez correctement cet équipement conformément à son Manuel d'Utilisation et aux réglementations nationales, gouvernementales et locales.
- Installer et mettre à la terre correctement cet appareil conformément à son manuel d'utilisation et aux codes nationaux, provinciaux et municipaux.
- Toujours vérifier la terre du cordon d'alimentation – Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Les câbles doivent être exempts d'humidité, d'huile et de graisse; protégez-les contre les étincelles et les pièces métalliques chaudes.
- Vérifier fréquemment le cordon d'alimentation pour voir s'il n'est pas endommagé ou dénudé – remplacer le cordon immédiatement s'il est endommagé – un câble dénudé peut provoquer une électrocution.
- Mettre l'appareil hors tension quand on ne l'utilise pas.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct – ne pas utiliser le connecteur de pièce ou le câble de retour.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretenir l'appareil conformément à ce manuel.
- Porter un harnais de sécurité quand on travaille en hauteur.
- Maintenir solidement en place tous les panneaux et capots.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.
- Ne pas raccorder plus d'une électrode ou plus d'un câble de masse à une même borne de sortie de soudage. Débrancher le câble pour le procédé non utilisé.


Il reste une TENSION DC NON NÉGLIGEABLE dans les sources de soudage onduleur UNE FOIS le moteur coupé.

- Couper l'alimentation du poste et décharger les condensateurs d'entrée comme indiqué dans la Section Maintenance avant de toucher des composants.



LES PIÈCES CHAUDES peuvent provoquer des brûlures.

- Ne pas toucher à mains nues les parties chaudes.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



DES PIÈCES DE METAL ou DES SALETES peuvent provoquer des blessures dans les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.



LES FUMÉES ET LES GAZ peuvent être dangereux.


Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.

- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser une ventilation forcée au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est médiocre, porter un respirateur anti-vapeurs approuvé.
- Lire et comprendre les spécifications de sécurité des matériaux (MSDS) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyants et les dégraissages.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz comprimé en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.


- Porter un casque de soudage approuvé muni de verres filtrants approprié pour protéger visage et yeux pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des lunettes de sécurité avec écrans latéraux même sous votre casque.
- Avoir recours à des écrans protecteurs ou à des rideaux pour protéger les autres contre les rayonnements les éblouissements et les étincelles ; prévenir toute personne sur les lieux de ne pas regarder l'arc.
- Porter des vêtements confectionnés avec des matières résistantes et ignifuges (cuir, coton lourd ou laine) et des bottes de protection.



LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 et AWS A6.0 (voir les Normes de Sécurité).
- Ne soudez pas si l'air ambiant est chargé de particules, gaz, ou vapeurs inflammables (vapeur d'essence, par exemple).
- Brancher le câble de masse sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution, d'étincelles et d'incendie.
- Ne pas utiliser le poste de soudage pour dégelé des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les porter.
- Suivre les recommandations dans OSHA 1910.252(a)(2)(iv) et NFPA 51B pour les travaux à chaud et avoir de la surveillance et un extincteur à proximité.



LE BRUIT peut affecter l'ouïe.


Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.



Les CHAMPS ÉLECTROMAGNÉTIQUES (CEM) peuvent affecter les implants médicaux.

- Les porteurs de stimulateurs cardiaques et autres implants médicaux doivent rester à distance.
- Les porteurs d'implants médicaux doivent consulter leur médecin et le fabricant du dispositif avant de s'approcher de la zone où se déroule du soudage à l'arc, du soudage par points, du gougeage, de la découpe plasma ou une opération de chauffage par induction.




Si des BOUTEILLES sont endommagées, elles pourront exploser.

Des bouteilles de gaz comprimé protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz comprimé, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Ne pas tenir la tête en face de la sortie en ouvrant la soupape de la bouteille.
- Maintenir le chapeau de protection sur la soupape, sauf en cas d'utilisation ou de branchement de la bouteille.
- Utiliser les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever et déplacer les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.

2-3. Dangers existant en relation avec le moteur



L'EXPLOSION DE LA BATTERIE peut provoquer des blessures.

- Toujours porter une protection faciale, des gants en caoutchouc et vêtements de protection lors d'une intervention sur la batterie.
- Arrêter le moteur avant de débrancher ou de brancher des câbles de batterie, des câbles de chargeur de batterie (le cas échéant) ou de batterie d'entretien.
- Éviter de provoquer des étincelles avec les outils en travaillant sur la batterie.
- Ne pas utiliser l'appareil de soudage pour charger des batteries ou faire démarrer des véhicules à l'aide de câbles de démarrage, sauf si l'appareil dispose d'une fonctionnalité de charge de batterie destinée à cet usage.
- Observer la polarité correcte (+ et -) sur les batteries.
- Débrancher le câble négatif (-) en premier lieu. Le rebrancher en dernier lieu.
- Les sources d'étincelles, flammes nues, cigarettes et autres sources d'inflammation doivent être maintenues à l'écart des batteries. Ces dernières produisent des gaz explosifs en fonctionnement normal et en cours de charge.
- Respecter les consignes du fabricant de la batterie pour travailler sur une batterie ou à proximité.



LE CARBURANT MOTEUR peut provoquer un incendie ou une explosion.

- Arrêter le moteur avant de vérifier le niveau de carburant ou de faire le plein.
- Ne pas faire le plein en fumant ou proche d'une source d'étincelles ou d'une flamme nue.
- Ne pas faire le plein de carburant à ras bord; prévoir de l'espace pour son expansion.
- Faire attention de ne pas renverser de carburant. Nettoyer tout carburant renversé avant de faire démarrer le moteur.
- Jeter les chiffons dans un récipient ignifuge.
- Toujours garder le pistolet en contact avec le réservoir lors du remplissage.



Les PIÈCES MOBILES peuvent causer des blessures.

- S'abstenir de toucher des parties mobiles telles que des ventilateurs, courroies et rotors.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Arrêter le moteur avant d'installer ou brancher l'appareil.
- Lorsque cela est nécessaire pour des travaux d'entretien et de dépannage, faire retirer les portes, panneaux, recouvrements ou dispositifs de protection uniquement par du personnel qualifié.
- Pour empêcher tout démarrage accidentel pendant les travaux d'entretien, débrancher le câble négatif (-) de batterie de la borne.
- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Remettre en place les portes, panneaux, recouvrements ou dispositifs de protection à la fin des travaux d'entretien et avant de mettre le moteur en marche.
- Avant d'intervenir, déposer les bougies ou injecteurs pour éviter la mise en route accidentelle du moteur.
- Bloquer le volant moteur pour éviter sa rotation lors d'une intervention sur le générateur.



LES ÉTINCELLES À L'ÉCHAPPEMENT peuvent provoquer un incendie.

- Empêcher les étincelles d'échappement du moteur de provoquer un incendie.
- Utiliser uniquement un pare-étincelles approuvé – voir codes en vigueur.




LES PIÈCES CHAUDES peuvent provoquer des brûlures.

- Ne pas toucher des parties chaudes à mains nues.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.




LA VAPEUR ET LE LIQUIDE DE REFROIDISSEMENT CHAUD peuvent provoquer des brûlures.

- Il est préférable de vérifier le liquide de refroidissement une fois le moteur refroidi pour éviter de se brûler.
- Toujours vérifier le niveau de liquide de refroidissement dans le vase d'expansion (si présent), et non dans le radiateur (sauf si précisé autrement dans la section maintenance du manuel du moteur).
- Si le moteur est chaud et que le liquide doit être vérifié, opérer comme suivant.
- Mettre des lunettes de sécurité et des gants, placer un torchon sur le bouchon du radiateur.
- Dévisser le bouchon légèrement et laisser la vapeur s'échapper avant d'enlever le bouchon.



L'utilisation d'un groupe autonome à l'intérieur PEUT VOUS TUER EN QUELQUES MINUTES.

- Les fumées d'un groupe autonome contiennent du monoxyde de carbone. C'est un poison invisible et inodore.
- JAMAIS utiliser dans une maison ou garage, même avec les portes et fenêtres ouvertes.
- Uniquement utiliser à l'EXTERIEUR, loin des portes, fenêtres et bouches aération.



L'ACIDE DE LA BATTERIE peut provoquer des brûlures dans les YEUX et sur la PEAU.


- Ne pas renverser la batterie.
- Remplacer une batterie endommagée.
- Rincer immédiatement les yeux et la peau à l'eau.



LA CHALEUR DU MOTEUR peut provoquer un incendie.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Tenir à distance les produits inflammables de l'échappement.

2-4. Dangers liés à l'air comprimé




Un ÉQUIPEMENT PNEUMATIQUE risque de provoquer des blessures ou même la mort.

- Une installation ou une utilisation incorrecte de cet appareil pourrait conduire à des dégâts matériels ou corporels. Seul un personnel qualifié est autorisé à installer, utiliser et entretenir cet appareil conformément à son manuel d'utilisation, aux normes industrielles et aux codes nationaux, d'état ou locaux.
- Ne pas dépasser le débit nominal ou la capacité du compresseur ou de tout équipement du circuit d'air comprimé. Concevoir le circuit d'air comprimé de telle sorte que la défaillance d'un composant ne risque pas de provoquer un accident matériel ou corporel.
- Avant d'intervenir sur le circuit d'air comprimé, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit d'air ne peut être mis sous pression par inadvertance.
- Ne pas intervenir sur le circuit d'air comprimé lorsque l'appareil fonctionne. Seul un personnel qualifié est autorisé, et appliquant les consignes du fabricant.
- Ne pas modifier ou altérer le compresseur ou les équipements fournis par le fabricant. Ne pas débrancher, désactiver ou neutraliser les équipements de sécurité du circuit d'air comprimé.
- Utiliser uniquement des composants et accessoires homologués par le fabricant.
- Se tenir à l'écart de tout point présentant un danger de pincement ou d'écrasement créé par l'équipement raccordé au circuit d'air comprimé.
- Ne pas intervenir sous ou autour d'un équipement qui n'est soutenu que par la pression pneumatique. Soutenir l'équipement de façon appropriée par un moyen mécanique.




MÉTAL CHAUD provenant du découpage ou du gougeage à l'arc risque de provoquer un incendie ou une explosion.

- Ne pas découper ou gouger à proximité de produits inflammables.
- Attention aux risques d'incendie: tenir un extincteur à proximité.



L'AIR COMPRIMÉ risque de provoquer des blessures ou même la mort.



- Avant d'intervenir sur le circuit d'air comprimé, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit d'air ne peut être mis sous pression par inadvertance.
- Détendre la pression avant de débrancher ou de brancher des canalisations d'air.
- Avant d'utiliser l'appareil, contrôler les composants du circuit d'air comprimé, les branchements et les flexibles en recherchant tout signe de détérioration, de fuite et d'usure.
- Ne pas diriger un jet d'air vers soi-même ou vers autrui.
- Pour intervenir sur un circuit d'air comprimé, porter un équipement de protection tel que des lunettes de sécurité, des gants de cuir, une chemise et un pantalon en tissu résistant, des chaussures montantes et une coiffe.
- Pour rechercher des fuites, utiliser de l'eau savonneuse ou un détecteur à ultrasons, jamais les mains nues. En cas de détection de fuite, ne pas utiliser l'équipement.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de mettre en marche l'appareil.
- En cas d'injection d'air dans la peau ou le corps, demander immédiatement une assistance médicale.



L'INHALATION D'AIR COMPRIMÉ risque de provoquer des blessures ou même la mort.

- Ne pas inhaler d'air comprimé.
- Utiliser l'air comprimé uniquement pour découper ou gouger ainsi que pour l'outillage pneumatique.



Une PRESSION D'AIR RÉSIDUELLE ET DES FLEXIBLES QUI FOUETTENT risquent de provoquer des blessures.

- Détendre la pression pneumatique des outils et circuits avant d'entretenir, ajouter ou changer des accessoires et avant d'ouvrir le bouchon de vidange ou de remplissage d'huile du compresseur.



Les PIÈCES MOBILES peuvent causer des blessures.

- S'abstenir de toucher des parties mobiles telles que des ventilateurs, courroies et rotors.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.

- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Avant d'intervenir sur le circuit d'air comprimé, couper l'alimentation électrique, verrouiller et étiqueter l'appareil,


détendre la pression et s'assurer que le circuit d'air ne peut être mis sous pression par inadvertance.

- Demander seulement à un personnel qualifié d'enlever les dispositifs de sécurité ou les recouvrements pour effectuer, s'il y a lieu, des travaux d'entretien et de dépannage.
- Remettre en place les portes, panneaux, recouvrements ou dispositifs de protection à la fin des travaux d'entretien et avant de mettre le moteur en marche.



DES PIÈCES CHAUDES peuvent provoquer des brûlures graves.

- Ne pas toucher de pièces chaudes du compresseur ou du circuit d'air.
- Prévoir une période de refroidissement avant d'intervenir sur l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



LIRE LES INSTRUCTIONS.

- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.


- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'entretien en respectant les manuels d'utilisation, les normes industrielles et les codes nationaux, d'état et locaux.

2-5. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance



Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.




LE SURCHAUFFEMENT peut endommager le moteur électrique.

- Arrêter ou déconnecter l'équipement avant de démarrer ou d'arrêter le moteur.
- Ne pas laisser tourner le moteur trop lentement sous risque d'endommager le moteur électrique à cause d'une tension et d'une fréquence trop faibles.
- Ne pas brancher de moteur de 50 ou de 60 Hz à la prise de 100 Hz, s'il y a lieu.




LA CHUTE DE L'ÉQUIPEMENT peut provoquer des blessures.

- Utiliser l'anneau de levage pour lever l'appareil et les accessoires correctement installés seuls, PAS les bouteilles de gaz. Ne pas dépasser le poids nominal maximal de l'œilleton (voir les spécifications).
- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.
- Tenir l'équipement (câbles et cordons) à distance des véhicules mobiles lors de toute opération en hauteur.
- Suivre les consignes du Manuel des applications pour l'équation de levage NIOSH révisée (Publication N°94-110) lors du levage manuel de pièces ou équipements lourds.



LES ÉTINCELLES PROJÉTÉES peuvent provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manœuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.



Les PIÈCES MOBILES peuvent causer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.



LA SORTIE DE RECHARGE et L'EXPLOSION DE LA BATTERIE peuvent provoquer des blessures.


La recharge de batterie n'existe pas sur tous les modèles.

- Toujours porter une protection faciale, des gants en caoutchouc et vêtements de protection lors d'une intervention sur la batterie.
- Arrêter le moteur avant de débrancher ou de brancher des câbles de batterie, des câbles de chargeur de batterie (le cas échéant) ou de batterie d'entretien.
- Eviter de provoquer des étincelles avec les outils en travaillant sur la batterie.
- Ne pas utiliser l'appareil de soudage pour charger des batteries ou faire démarrer des véhicules à l'aide de câbles de démarrage, sauf si l'appareil dispose d'une fonctionnalité de charge de batterie destinée à cet usage.
- Observer la polarité correcte (+ et -) sur les batteries.
- Débrancher le câble négatif (-) en premier lieu. Le rebrancher en dernier lieu.
- Les sources d'étincelles, flammes nues, cigarettes et autres sources d'inflammation doivent être maintenues à l'écart des batteries. Ces dernières produisent des gaz explosifs en fonctionnement normal et en cours de charge.
- Respecter les consignes du fabricant de la batterie pour travailler sur une batterie ou à proximité.
- Les opérations de charge de batterie ne doivent être effectuées que par des personnes qualifiées.
- Pour enlever la batterie d'un véhicule pour la recharge, débrancher tout d'abord le câble négatif (-) et le rebrancher en dernier lieu. Pour éviter un arc, s'assurer que tous les accessoires sont débranchés.
- Ne charger que des batteries plomb-acide. Ne pas utiliser le chargeur de batterie pour alimenter un autre circuit électrique basse tension ou pour charger des batteries sèches.
- Ne pas charger une batterie gelée.
- Ne pas utiliser de câbles de charge endommagés.
- Ne pas charger des batteries dans un espace fermé ou en l'absence d'une ventilation.
- Ne pas charger une batterie dont les bornes sont desserrées ou présentant une détérioration comme par exemple un boîtier ou un couvercle fissuré.
- Avant de charger une batterie, sélectionner la tension de charge correspondant à la tension de la batterie.
- Régler les commandes de charge de batterie sur la position d'arrêt avant de brancher la batterie. Veiller à ce que les pinces de charge ne se touchent pas.
- Ranger les câbles de charge à distance du capot, des portes et des pièces mobiles du véhicule.




LES FILS DE SOUDAGE peuvent provoquer des blessures.

- Ne pas appuyer sur la gâchette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Laisser l'équipement refroidir ; respecter le facteur de marche nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.




LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.




UNE REMORQUE QUI BASCULE peut provoquer des blessures.

- Utiliser les supports de la remorque ou des blocs pour soutenir le poids.
- Installer convenablement le poste sur la remorque comme indiqué dans le manuel s'y rapportant.




LIRE LES INSTRUCTIONS.

- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.
- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'entretien en respectant les manuels d'utilisation, les normes industrielles et les codes nationaux, d'état et locaux.



LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.




- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.




LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.


2-6. Proposition californienne 65 Avertissements

-  Les équipements de soudage et de coupage produisent des fumées et des gaz qui contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des malformations congénitales et, dans certains cas, des cancers. (Code de santé et de sécurité de Californie, chapitre 25249.5 et suivants)
-  Les batteries, les bornes et autres accessoires contiennent du plomb et des composés à base de plomb, produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation. *Se laver les mains après manipulation.*
-  Ce produit contient des produits chimiques, notamment du plomb, dont l'État de Californie reconnaît qu'ils provoquent des cancers, des malformations congénitales ou d'autres problèmes de procréation. *Se laver les mains après utilisation.*

Pour les moteurs à essence :

-  Les gaz d'échappement des moteurs contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation.

Pour les moteurs diesel :

-  Les gaz d'échappement des moteurs diesel et certains de leurs composants sont reconnus par l'État de Californie comme provoquant des cancers et des malformations congénitales ou autres problèmes de procréation.

2-7. Principales normes de sécurité

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, is available as a free download from the American Welding Society at <http://www.aws.org> or purchased from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for Welding and Cutting Containers that have Held Combustibles, American Welding Society Standard AWS A6.0, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 14501 George Carter Way, Suite 103, Chantilly, VA 20151 (phone: 703-788-2700, website: www.cganet.com).

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Battery Chargers, CSA Standard C22.2 NO 107.2-01, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite

100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 25 West 43rd Street, New York, NY 10036 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 OSHA Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

Portable Generators Safety Alert, U.S. Consumer Product Safety Commission (CPSC), 4330 East West Highway, Bethesda, MD 20814 (phone: 301-504-7923, website: www.cpsc.gov/cpsc/pub/pubs/portgen.pdf).

Applications Manual for the Revised NIOSH Lifting Equation, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (phone: 1-800-232-4636, website: www.cdc.gov/NIOSH).

2-8. Informations relatives aux CEM

Le courant électrique qui traverse tout conducteur génère des champs électromagnétiques (CEM) à certains endroits. Le courant de soudage crée un CEM autour du circuit et du matériel de soudage. Les CEM peuvent créer des interférences avec certains implants médicaux comme des stimulateurs cardiaques. Des mesures de protection pour les porteurs d'implants médicaux doivent être prises: par exemple, des restrictions d'accès pour les passants ou une évaluation individuelle des risques pour les soudeurs. Tous les soudeurs doivent appliquer les procédures suivantes pour minimiser l'exposition aux CEM provenant du circuit de soudage:

1. Rassembler les câbles en les torsadant ou en les attachant avec du ruban adhésif ou avec une housse.
2. Ne pas se tenir au milieu des câbles de soudage. Disposer les câbles d'un côté et à distance de l'opérateur.
3. Ne pas courber et ne pas entourer les câbles autour de votre corps.


4. Maintenir la tête et le torse aussi loin que possible du matériel du circuit de soudage.
5. Connecter la pince sur la pièce aussi près que possible de la soudure.
6. Ne pas travailler à proximité d'une source de soudage, ni s'asseoir ou se pencher dessus.
7. Ne pas souder tout en portant la source de soudage ou le dévidoir.











En ce qui concerne les implants médicaux :












Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gougeage, du coupage plasma ou de chauffage par induction. Si le médecin approuve, il est recommandé de suivre les procédures précédentes.

SECTION 3 – DEFINITIONS

3-1. Additional Safety Symbols And Definitions

 Some symbols are found only on CE products.

| | |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Warning! Watch Out! There are possible hazards as shown by the symbols.</p> <p style="text-align: right;">Safe1 2012-05</p> |
|  | <p>Wear dry insulating gloves. Do not touch electrode with bare hand. Do not wear wet or damaged gloves.</p> <p style="text-align: right;">Safe2 2012-05</p> |
|  | <p>Protect yourself from electric shock by insulating yourself from work and ground.</p> <p style="text-align: right;">Safe3 2012-05</p> |
|  | <p>Keep your head out of the fumes.</p> <p style="text-align: right;">Safe6 2012-05</p> |
|  | <p>Use forced ventilation or local exhaust to remove the fumes.</p> <p style="text-align: right;">Safe8 2012-05</p> |
|  | <p>Use ventilating fan to remove fumes.</p> <p style="text-align: right;">Safe10 2012-05</p> |
|  | <p>Keep flammables away from welding. Do not weld near flammables.</p> <p style="text-align: right;">Safe12 2012-05</p> |
|  | <p>Welding sparks can cause fires. Have a fire extinguisher nearby, and have a watchperson ready to use it.</p> <p style="text-align: right;">Safe14 2012-05</p> |
|  | <p>Do not weld on drums or any closed containers.</p> <p style="text-align: right;">Safe16 2012-05</p> |
|  | <p>Do not remove or paint over (cover) the label.</p> <p style="text-align: right;">Safe20 2012-05</p> |

| | |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Do not work on unit if engine is running. Stop engine first.</p> <p style="text-align: right;">Safe21 2012-05</p> |
|  | <p>Do not smoke while fueling or if near fuel.</p> <p style="text-align: right;">Safe22 2012-05</p> |
|  | <p>Stop engine before fueling.</p> <p style="text-align: right;">Safe23 2012-05</p> |
|  | <p>Do not fuel a hot engine.</p> <p style="text-align: right;">Safe24 2012-05</p> |
|  | <p>Use lift eye to lift unit and properly installed accessories only, not gas cylinders. Do not exceed maximum lift eye rating (see Specifications).</p> <p style="text-align: right;">Safe25 2012-05</p> |
|  | <p>Wear hat and safety glasses. Use ear protection and button shirt collar. Use welding helmet with correct shade of filter. Wear complete body protection.</p> <p style="text-align: right;">Safe38 2012-05</p> |
|  | <p>Become trained and read the instructions before working on the machine or welding.</p> <p style="text-align: right;">Safe40 2012-05</p> |
|  | <p>Engine fuel plus flames or sparks can cause fire.</p> <p style="text-align: right;">Safe45 2012-05</p> |
|  | <p>Remove unit from shipping crate. Remove Owner's Manual from unit. Follow instructions to install muffler.</p> <p style="text-align: right;">Safe46 2012-05</p> |
|  | <p>Read Owner's Manual. Read labels on unit.</p> <p style="text-align: right;">Safe47 2012-05</p> |
|  | <p>Read Owner's Manual. Follow instructions to activate battery.</p> <p style="text-align: right;">Safe48 2012-05</p> |

3-2. Miscellaneous Symbols And Definitions

| | | | | | | | |
|----------------------|------------------------|----------------------|---------------------------------------|----------------------|------------------------------------------------------|----------------------|-----------------------------|
| | Stop Engine | | Fast (Run, Weld/Power) | | Slow (Idle) | | Start Engine |
| | Starting Aid (Preheat) | | Battery (Engine) | | Engine Oil Pressure | | Engine Oil |
| | Check Injectors/Pump | | Check Valve Clearance | | Fuel | | Protective Earth (Ground) |
| + | Positive | - | Negative | | Certified/Trained Mechanic | | Welding Arc |
| A | Amperes | V | Volts | | | | Remote |
| | Engine | | Air Temperature Or Engine Temperature | | Output | | Alternating Current |
| | Stick (SMAW) Welding | | Constant Current (CC) | | FCAW Welding | | TIG (GTAW) Welding |
| | Time | h | Hours | s | Seconds | 1 | Single Phase |
| 3 | Three Phase | | Read Operator's Manual | | Circuit Protection | | Do Not Switch While Welding |
| | Electrode Connection | | Work Connection | | Engine-Driven, Three-Phase Alternator With Rectifier | Hz | Hertz |
| X | Duty Cycle | U₀ | Rated No Load Voltage (Average) | U₂ | Conventional Load Voltage | n | Rated Load Speed |
| n₁ | Rated Idle Speed | n₀ | Rated No Load Speed | I | Current | I₂ | Rated Welding Current |

SECTION 4 – SPECIFICATIONS

4-1. Weld, Power, And Engine Specifications

| Weld Process | Output Mode | Weld Output Range | Weld Output Rated at 104°F (40°C) | Maximum Open-Circuit Voltage | Generator Power Output Rated at 104°F (40°C) | Sound Level at Rated Output, 23ft (7m) |
|-------------------|----------------------------------------------------------------------------|-------------------|---------------------------------------------------------------------------------------------|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|
| CC/DC (Stick\TIG) | Paralleled (combined) | 40-800A | 500A at 40V, 100% Duty Cycle* 700A at 28V, 60% Duty Cycle | 85VDC◇ | 5500 Watts Peak 4000 Watts Continuous Additional Generator Power for Deluxe Models 3 phase: 27,000 Watts Peak 20,000 Watts Continuous 1 phase: 19,000 Watts Peak 12,000 Watts Continuous | 75dB (100 Lwa) |
| | Separate (dual/outputs) | 20-400A Each Side | 300A at 32V, 100% Duty Cycle* Each Side 400A at 36V, 40% Duty Cycle* One Side only | | | |
| CV/DC (MIG/FCAW) | Paralleled (combined) | 14-40VDC | 500A at 39V, 100% Duty Cycle* 700A at 28V, 60% Duty Cycle | | | |
| | Separate (dual/outputs) | 14-40VDC Each | 300A at 29V, 100% Duty Cycle* Each Side 400A at 34V, 40% Duty Cycle* One Side only | | | |
| Engine | Deutz D2011L04i Air/Oil-Cooled, Four Cylinder, 48.7 HP Diesel Engine | | Fuel Capacity | 25 gal (95 L) | | |

* Meets NEMA and IEC Ratings.


◇ With Low OCV switch (Voltage Reducing Device, VRD) enabled, open-circuit voltage is 13 to 15 volts DC until arc initiation.

4-2. Environmental Specifications


| IP Rating | Operating Temperature Range |
|----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|
| IP23S This equipment is designed for outdoor use. It may be stored, but is not intended to be used outside during precipitation unless sheltered. | -40 to 104°F (-40 to +40°C) |

4-3. Dimensions, Weights, And Operating Angles

| Dimensions | |
|--------------------------------------------------------------------------------------------------|---------------------------------------------------|
| Height | 60 in. (1524 mm) (to top of muffler) |
| Width | 28-1/2 in. (724 mm) (mtg. brackets turned in) |
| | 30-3/4 in. (781 mm) (mtg. brackets turned out) |
| Depth | 65-1/8 in. (1654 mm) |
| A | 65-1/8 in. (1654 mm) |
| B* | 56 in. (1422 mm) |
| C* | 46-1/2 in. (1181) |
| D* | 9-5/8 in. (244 mm) |
| E | 27-1/2 in. (699 mm) |
| F | 1 in. (25 mm) |
| G | 29-13/16 in. (757 mm) |
| H | 9/16 in. (14 mm) Dia. 4 Holes |
| * With mounting brackets in center position. Dimensions vary with location of mounting brackets. | |
| Weight | |
| No fuel: 1729 lb (784 kg) W/fuel: 1919 lb (870 kg) | |
| Lifting Eye Weight Rating: 2500 lb (1134 kg) Maximum | |



- ⚠ Do not exceed tilt angles or engine could be damaged or unit could tip.**
- ⚠ Do not move or operate unit where it could tip.**




907 520-1


4-4. Volt-Ampere Curves

The volt-ampere curves show the minimum and maximum voltage and amperage output capabilities of the welding generator. Curves of all other settings fall between the curves shown.


A. Stick Mode



B. TIG Mode




C. MIG Mode




4-5. Volt-Ampere Curves For Paralleled Output

A. Stick Mode




The volt-ampere curves show the minimum and maximum voltage and amperage output capabilities of the welding generator. Curves of all other settings fall between the curves shown.


B. TIG Mode




C. MIG Mode



4-6. Fuel Consumption




4-7. Duty Cycle And Overheating




4-8. AC Generator Power Curves

The AC power curve shows the generator power in amperes.

A. Single Phase 4 kW




B. Three Phase Optional 380 VAC 20 kW




4-7. AC Generator Power Curves (Continued)

C. Single Phase 12 kW

The AC power curve shows the generator power in amperes.



D. Three Phase North American 20 kW



SECTION 5 – INSTALLATION


5-1. Serial Number And Rating Label Locations

The serial number and rating information for this product is located on the front. Use rating label to determine input power requirements and/or rated output. For future reference, write serial number in space provided on back cover of this manual.

5-2. Installing Welding Generator



Movement





- ⚠** Do not move or operate unit where it could tip.
- ⚠** Always securely fasten welding generator onto transport vehicle or trailer and comply with all DOT and other applicable codes.

NOTICE – Do not install unit where air flow is restricted or engine may overheat.

☞ See Section 4-3 for lifting eye rating.

☞ See Section 5-3 for mounting information.

Location/Airflow Clearance





install3 2008-01 – Ref. 800 652 / Ref. 800 477-A / 803 274 / 804 712

5-3. Mounting Welding Generator



Supporting The Unit



⚠ Do not weld on base. Welding on base can cause fuel tank fire or explosion. Weld only on the four mounting brackets or bolt unit down.

NOTICE – Do not mount unit by supporting the base only at the four mounting brackets. Use cross-supports to adequately support unit and prevent damage to base.

Mounting Surface:

1 Cross-Supports
2 Mounting Brackets (Supplied)
Mount unit on flat surface or use cross-supports to support base. Secure unit with mounting brackets.

3 1/2 in. Bolt And Washer (Minimum – Not Supplied)
4 3/8-16 x 1 in. Screws (Supplied)

To Bolt Unit In Place:



Remove hardware securing the four mounting brackets to the base. Reverse brackets and reattach to base with original hardware.


Mount unit to truck or trailer with 1/2 in. (12 mm) or larger hardware (not supplied).

To Weld Unit In Place:

Weld unit to truck or trailer only at the four mounting brackets.



Using Mounting Brackets




Tools Needed:
 9/16 in.

install3 2008--01 803 274 / 200 864-A / 803 231

5-4. Grounding Generator To Truck Or Trailer Frame



rot_grnd2 2012-03 - 800 652-D

- Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.
- Also see AWS Safety & Health Fact Sheet No. 29, Grounding of Portable And Vehicle Mounted Welding Generators.
- Bed liners, shipping skids, and some running gear insulate the welding generator from the vehicle

frame. Always connect a ground wire from the generator equipment grounding terminal to bare metal on the vehicle frame as shown.




- Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacles to power life support equipment.


- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame


Connect cable from equipment ground terminal to metal vehicle frame. Use #8 AWG or larger insulated copper wire.

Electrically bond generator frame to vehicle frame by metal-to-metal contact.

5-5. Installing Exhaust Pipe







- Stop engine and let cool.**
- Point exhaust pipe in desired direction but always away from front panel and direction of travel.

Tools Needed:

1/2 in.

Exhaust1 2008-01 Ref. 803 604 / Ref. 215 664

5-7. Engine Prestart Checks



NOTICE – Follow run-in procedure in engine manual. If unburned fuel and oil collect in exhaust pipe, see Section 10.

907 520-4

☞ **Check all engine fluids daily.**

Engine must be cold and on a level surface. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high.

☞ *This unit has a low oil pressure shutdown switch. However, some conditions may cause engine damage before the engine shuts down. Check oil level often and do not use the oil pressure shutdown system to monitor oil level.*

NOTICE – Follow run-in procedure in engine manual. If unburned fuel and oil collect in exhaust pipe, see Section 10.

Fuel

NOTICE – Do not use gasoline. Gasoline will damage engine.

The unit is shipped with enough fuel to prevent air from entering fuel system. Add fresh diesel fuel before starting (see engine maintenance label for fuel specifications). Leave filler neck empty to allow room for expansion.

Engine stops if fuel level is low.

Oil

After fueling, check oil with unit on level surface. If oil is not up to full mark on dipstick, add oil (see maintenance label).

☞ **To improve cold weather starting:**



Use Starting Aid switch (see Section 6-2).

Keep battery in good condition. Store battery in warm area.


Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information.

Use correct grade oil for cold weather (see Section 8-1).

5-9. Making Dual Operator CC Weld Connections w/ Separate Work Cables



Tools Needed:




Optional Weld Selector switch shown.

Welder A (Left Side)

Direct Current Electrode Positive (DCEP) connections are shown.

Welder B (Right Side)



Ref. 251 340-A / Ref. 802 292-A

⚠ Stop engine.

NOTICE – Do not exceed machine duty cycle.

Use Dual Operator mode for CC and CV welding (see Section 6-2).

See Section 5-16 for proper cable size.

1 Electrode Holder Cables



2 Work Cables

For Stick/TIG welding Direct Current Electrode Positive (DCEP), connect work cables to Negative (-) terminals and electrode holder cables to Positive (+) terminals.


For Stick/TIG Direct Current Electrode Negative (DCEN), connect work cables to Positive (+) terminals and electrode holder cables to Negative (-) terminals.

Be sure Process Selector switches are set correctly. See Section 6-3.

5-10. Making Dual Operator Mode CC Weld Connections w/ Common Work Cable



Tools Needed:




Optional Weld Selector switch shown.

Welder A (Left Side)

Direct Current Electrode Positive (DCEP) connections are shown.

Welder B (Right Side)



Ref. 251 340-A / Ref. 802 292-A

⚠ Stop engine.

⚠ Failure to properly size and connect weld cables may cause excessive heat and start a fire, or damage your machine.

NOTICE – When making weld connections with a common work cable, connect weld cable of adequate size between Negative (-) weld output terminals, and connect a single weld cable of adequate size from Welder B (right) Negative (-) terminal to the workpiece.

NOTICE – When using these connections as a common work terminal, all connections must be of the same polarity.

NOTICE – For common work connection,

work cable must be able to carry combined weld output of both modules (see Section 5-16 for proper cable size).

NOTICE – Do not exceed machine duty cycle.

Use Dual Operator mode for CC and CV welding (see Section 6-2).

- 1 Electrode Holder Cables
- 2 Work Jumper Cable
- 3 Common Work Cable

For Stick/TIG welding Direct Current Electrode Positive (DCEP), connect common work cable and work jumper cable to Welder B (right) Negative (-) terminal. Connect

other end of work jumper cable to Welder A (left) Negative (-) terminal.





Connect electrode holder cables to Positive (+) terminals.



For Stick/TIG Direct Current Electrode Negative (DCEN), connect common work cable and work jumper cable to Welder B (right) Positive (+) terminal. Connect other end of work jumper cable to Welder A (left) Positive (+) terminal.

Connect electrode holder cables to Negative (-) terminals.


Be sure Process Selector switches are set correctly. See Section 6-3.

5-11. Making Dual Operator CV Weld Connections w/ Separate Work Cables


Tools Needed:


 3/4 in.

☞ *Optional Weld Selector switch shown.*


Direct Current Electrode Positive (DCEP) connections are shown.

Welder A (Left) Side





Welder B (Right) Side



Ref. 251 340-A / Ref. 802 292-A

⚠ Stop engine.

NOTICE – Do not exceed machine duty cycle.

☞ Use Dual Operator mode for CC and CV welding (see Section 6-2). See Section 5-16 for proper cable size.

1 Wire Feeder Cables



2 Work Cables

For MIG and FCAW welding Direct Current Electrode Positive (DCEP), connect work cables to Negative (-) terminals and wire feeder cables to Positive (+) terminals.


For MIG and FCAW Direct Current Electrode Negative (DCEN), connect work cables to Positive (+) terminals and wire feeder cables to Negative (-) terminals.

☞ Be sure Process Selector switches are set correctly. See Section 6-3.

5-12. Making Dual Operator CV Weld Connections w/ Common Work Cable



Tools Needed:




Optional Weld Selector switch shown.

Direct Current Electrode Positive (DCEP) connections are shown.

Welder A (Left Side)

Welder B (Right Side)



Ref. 251 340-A / Ref. 802 292-A

⚠ Stop engine.

⚠ Failure to properly size and connect weld cables may cause excessive heat and start a fire, or damage your machine.

NOTICE – When making weld connections with a common work cable, connect weld cable of adequate size between Negative (-) weld output terminals, and connect a single weld cable of adequate size from Welder B (right) Negative (-) terminal to the workpiece.

NOTICE – When using these connections as a common work terminal, all connections must be of the same polarity.

NOTICE – For common work connection, work cable must be able to carry combined

weld output of both modules (see Section 5-16 for proper cable size).

NOTICE – Do not exceed machine duty cycle.

For common work connection, work cable must be able to carry combined weld output of both CC weld output terminals (see Section 5-16 for proper cable size).

Use Dual Operator mode for CC and CV welding (see Section 6-2).

- 1 Wire Feeder Cables
- 2 Work Jumper Cable
- 3 Common Work Cable

For MIG and FCAW welding Direct Current Electrode Positive (DCEP), connect com-

mon work cable and work jumper cable to Welder B (right) Negative (-) terminal. Connect other end of work jumper cable to Welder A (left) Negative (-) terminal.



Connect wire feeder cables to Positive (+) terminals.

For MIG and FCAW Direct Current Electrode Negative (DCEN), connect common work cable and work jumper cable to Welder B (right) Positive (+) terminal. Connect other end of work jumper cable to Welder A (left) Positive (+) terminal.


Connect wire feeder cables to Negative (-) terminals.

Be sure Process Selector switches are set correctly. See Section 6-3.

5-13. Making Dual Operator CC And CV Weld Connections w/ Separate Work Cables



Tools Needed:




Optional Weld Selector switch shown.

Direct Current Electrode Positive (DCEP) connections are shown.

Welder A (Left Side)

Welder B (Right Side)



Ref. 251 340-A / Ref. 802 292-A

Stop engine.

NOTICE – Do not exceed machine duty cycle.

Use Dual Operator mode for CC and CV welding (see Section 6-2).

See Section 5-16 for proper cable size.

- 1 Electrode Holder Cable
- 2 Wire Feeder Cable
- 3 Work Cables

For Stick/TIG welding Direct Current Electrode Positive (DCEP), connect work cable to Negative (-) terminal and electrode holder cable to Positive (+) terminal.

For Stick/TIG Direct Current Electrode Negative (DCEN), connect work cable to Positive (+) terminal and electrode holder cable to Negative (-) terminal.


Be sure Process Selector switches are set correctly. See Section 6-3.


For MIG and FCAW welding Direct Current Electrode Positive (DCEP), connect work cable to Negative (-) terminal and wire feeder cable to Positive (+) terminal.

For MIG and FCAW Direct Current Electrode Negative (DCEN), connect work cable to Positive (+) terminal and wire feeder cable to Negative (-) terminal.

Be sure Process Selector switches are set correctly. See Section 6-3.

5-14. Making Dual Operator CC And CV Weld Connections w/ Common Work Cable



Tools Needed:
 3/4 in.


 Optional Weld Selector switch shown.

Direct Current Electrode Positive (DCEP) connections are shown.

Welder A (Left Side)

Welder B (Right Side)

 **Stop engine.**

 **Failure to properly size and connect weld cables may cause excessive heat and start a fire, or damage your machine.**


NOTICE – When making weld connections with a common work cable, connect weld cable of adequate size between Negative (-) weld output terminals, and connect a single weld cable of adequate size from Welder B (right) Negative (-) terminal to the workpiece.

NOTICE – When using these connections as a common work terminal, all connections must be of the same polarity.

NOTICE – For common work connection, work cable must be able to carry combined weld output of both modules (see Section

5-16 for proper cable size).

NOTICE – Do not exceed machine duty cycle.

 Use Dual Operator mode for CC and CV welding (see Section 6-2).


- 1 Electrode Holder Cable
- 2 Wire Feeder Cable
- 3 Work Jumper Cable
- 4 Common Work Cable

For Direct Current Electrode Positive (DCEP), connect common work cable and work jumper cable to Welder B (right) Negative (-) terminal. Connect other end of work jumper cable to Welder A (left) Negative (-) terminal.

Ref. 251 340-A / Ref. 802 292-A


Connect electrode holder cable to one Positive (+) terminal.

Connect wire feeder cable to remaining Positive(+) terminal.




 Be sure Process Selector switches are set correctly. See Section 6-3.

For Direct Current Electrode Negative (DCEN), connect common work cable and work jumper cable to Welder B (right) Positive (+) terminal. Connect other end of work jumper cable to Welder A (left) Positive (+) terminal.

Connect electrode holder cable to one Negative (-) terminal, and wire feeder cable to remaining Negative (-) terminal.

 Be sure Process Selector switches are set correctly. See Section 6-3.

5-15. Making Single Operator CC Weld Connections





☞ Optional Weld Selector switch shown.


**Welder B (right) Terminals
Inactive In Single Operator Mode**

Welder A (Left) Side

Direct Current Electrode Positive
(DCEP) connections are shown.



Tools Needed:



Ref. 251 340-A / Ref. 802 292-A

⚠ Stop engine.

NOTICE – Do not exceed machine duty cycle.

☞ *Welder B (right) weld output terminals are disabled in Single Operator mode. Connect only to Welder A (left) terminals for Single Operator mode operation.*

☞ *Use Single Operator mode for CC welding only. Welder B weld output terminals are disabled in Single Operator mode. (see Section 6-2).*

☞ *See Section 5-16 for proper cable size.*

- 1 Electrode Holder Cable
- 2 Work Cable


For Stick/TIG welding Direct Current Electrode Positive (DCEP), connect work cable to Negative (–) terminal and electrode holder cable to Positive (+) terminal.

For Stick/TIG Direct Current Electrode Negative (DCEN), connect work cable to Positive (+) terminal and electrode holder cable to Negative (–) receptacle.

☞ *Be sure Process Selector switch is set correctly. See Section 6-3.*

5-16. Weld Output Terminals And Selecting Cable Sizes*

NOTICE – The Total Cable Length in Weld Circuit (see table below) is the combined length of both weld cables. For example, if the power source is 100 ft (30 m) from the workpiece, the total cable length in the weld circuit is 200 ft (2 cables x 100 ft). Use the 200 ft (60 m) column to determine cable size.

|  Weld Output Terminals | Weld Cable Size** and Total Cable (Copper) Length in Weld Circuit Not Exceeding*** | | | | | | | | |
|-------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|-----------------------------------------------------|------------------------------------------------------|------------------------------------------------------|----------------------|----------------------|----------------------|-----------------------|-----------------------|
| | Welding Amperes | 100 ft (30 m) or Less | | 150 ft (45 m) | 200 ft (60 m) | 250 ft (70 m) | 300 ft (90 m) | 350 ft (105 m) | 400 ft (120 m) |
| | | 10 – 60% Duty Cycle AWG (mm²) | 60 – 100% Duty Cycle AWG (mm²) | 10 – 100% Duty Cycle AWG (mm²) | | | | | |
| | 100 | 4 (20) | 4 (20) | 4 (20) | 3 (30) | 2 (35) | 1 (50) | 1/0 (60) | 1/0 (60) |
| | 150 | 3 (30) | 3 (30) | 2 (35) | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 3/0 (95) |
| | 200 | 3 (30) | 2 (35) | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 4/0 (120) |
| | 250 | 2 (35) | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2x2/0 (2x70) | 2x2/0 (2x70) |
| | 300 | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x3/0 (2x95) |
| | 350 | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x3/0 (2x95) | 2x4/0 (2x120) |
| | 400 | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x4/0 (2x120) | 2x4/0 (2x120) |
| | 500 | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x4/0 (2x120) | 3x3/0 (3x95) | 3x3/0 (3x95) |
| | 600 | 3/0 (95) | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x4/0 (2x120) | 3x3/0 (3x95) | 3x4/0 (3x120) | 3x4/0 (3x120) |
| | 700 | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x4/0 (2x120) | 3x3/0 (3x95) | 3x4/0 (3x120) | 3x4/0 (3x120) | 4x4/0 (4x120) |
| | 800 | 4/0 (120) | 2x2/0 (2x70) | 2x3/0 (2x95) | 2x4/0 (2x120) | 3x4/0 (3x120) | 3x4/0 (3x120) | 4x4/0 (4x120) | 4x4/0 (4x120) |

* This chart is a general guideline and may not suit all applications. If cable overheats, use next size larger cable.


**Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere.
() = mm² for metric use

***For distances longer than those shown in this guide, call a factory applications rep. at 920-735-4505 (Miller) or 1-800-332-3281 (Hobart).

Ref. S-0007-J 2011-07

SECTION 6 – OPERATING WELDING GENERATOR

6-1. Front Panel Controls (See Section 6-2)



6-2. Description Of Front Panel Controls (See Section 6-1)



Engine Starting Controls

1 Preheat Switch

Use switch to energize starting aid for cold weather starting (see starting instructions following).

2 Engine Control Switch

Use switch to start engine, select engine speed, and stop engine.

In Run position, engine runs at weld/power speed. In Run/Idle position, engine runs at idle speed at no load and weld speed with load applied.

NOTICE – Diesel engines in MILLER equipment are meant to operate optimally at rated load. Using light or intermittent loads may cause wetstacking.

To Start:

NOTICE – Do not use ether.

☞ If engine does not start, let engine come to a complete stop before attempting re-start.

Above 32° F (0° C): turn Engine Control switch to Start. Release Engine Control switch when engine starts.

Below 32° F (0° C): turn engine control switch to Run position. Push Preheat switch up for 15 to 30 seconds. Turn Engine Control switch to Start. Release Engine Control switch and Preheat switch when engine starts.

☞ Do not operate Preheat switch for more than 60 seconds at a time.

To Stop: turn Engine Control switch to Off position.

Engine Gauges, Meters, And Lights

3 Engine Coolant Temperature Gauge

Normal temperature is 200 - 230° F (93 - 110° C). Engine stops if temperature exceeds 266° F (130° C).

4 Engine Oil Pressure Gauge

Normal pressure is 30 - 60 psi (206 - 414 kPa). Engine stops if pressure is below 22 psi (150 kPa).

☞ See Section 6-10 for complete fuel/hour gauge information.

5 Fuel/Hour Gauge

Use gauge to check fuel level, total engine operating hours, or hours to oil change.

To check fuel level or engine hours when engine is not running, turn Engine Control switch to Run/Idle position.

6 Engine Indicator Light

Light goes on and engine stops if fuel is low, engine temperature exceeds 266° F (130° C) or engine oil pressure is below 22 psi (150 kPa).

☞ Normal engine temperature is 200 - 230° F (93 - 110° C). Normal oil pressure is 30 - 60 psi (207 - 414 kPa).

NOTICE – Do not run engine until trouble is fixed.

Weld Meters

☞ Weld meters also work in combination to display troubleshooting help codes (see Section 8-8).

7 DC Ammeter

Ammeter displays preset amperage (Stick and TIG only) when not welding, and actual output amperage when welding.

To set amperage, turn Process/Contactor switch to Stick or TIG position. Turn V/A control until desired amperage is displayed on Ammeter. When welding is finished, ammeter displays weld amperage and then defaults to preset amperage.

8 DC Voltmeter

Voltmeter displays preset voltage (MIG welding) with contactor off, and actual output voltage with the contactor on. Voltmeter displays voltage at the weld output terminals, but not necessarily the welding arc due to resistance of cable and connections.

To set voltage, turn Process/Contactor switch to MIG or FCAW position. Turn V/A control until desired voltage is displayed on Voltmeter. When welding is finished, voltmeter displays weld voltage and then defaults to preset voltage.

Weld Controls

9 Voltage/Amperage Control

With Process/Contactor switch in any Stick or TIG setting, use control to adjust amperage. With Process/Contactor switch in any Wire (MIG or FCAW) position, use control to adjust

voltage. Control limits the remote amperage in Stick or TIG mode, but has no effect in Wire modes.

10 Process/Contactor Switch

See Section 6-3 for Process/Contactor switch information.

11 Remote Control Receptacle

Use receptacle to connect remote controls, wire feeders, and tools requiring 24 VAC.

When a remote control is connected to the Remote receptacle, the Auto Sense Remote feature automatically switches voltage/amperage control to the remote control (see Section 6-8).

With remote control connected, weld output is determined by a combination of front panel and remote control voltage/amperage settings.

If no remote control is connected to the Remote receptacle, the front panel Voltage/Amperage control adjusts voltage and amperage.

☞ If a remote device connected to Remote Receptacle is faulty or is disconnected during operation, the meters display Help 25 (see Section 8-8). Clear fault by stopping and restarting the unit or by turning Process/Contactor switch to another position.

12 Arc Control

See Section 6-4 for Arc Control information.

13 Optional Welder Selector Switch


Use switch to select Dual Operator or Single Operator welding mode.

Place switch in Welder A/Welder B (dual operator) position for CC and CV output from Welder A (left) and Welder B (right) weld output terminals. Control the weld output from the terminals on each side using the weld controls on that same side.

Place switch in Welder A (single operator) position for weld output from Welder A (left) weld output terminals only.

☞ Welder B (right) weld output terminals are disabled in Single Operator mode. Connect only to Welder A (left) terminals for Single Operator operation.

6-3. Process/Contactor Switch



1 Process/Contactor Switch

⚠ Weld output terminals are energized when Process/Contactor switch is in an Electrode Hot position and the engine is running.

Use switch to select weld process and weld output on/off control (see table below).

Place switch in Remote On/Off Switch Required positions to turn weld output on and off with a device connected to the Remote 14 receptacle.

Place switch in Electrode Hot positions for weld output to be on whenever the engine is running.

Use Stick mode for air carbon arc (CAC-A) cutting and gouging.

Use the Lift-Arc TIG mode for TIG (GTAW) welding using the Lift-Arc TIG starting procedure (see Section 6-7).

Ref. 251 246-A

| | Switch Setting | Typical Process Applications (DC Only) |
|------------------------|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ELECTRODE HOT | Electrode Hot – MIG VS | MIG solid wire uses a voltage sensing (VS) feeder that does not require a control cable back to the welding generator. |
| | Electrode Hot – FCAW VS | FCAW (Flux Cored Arc Welding) uses a voltage sensing (VS) feeder that does not require a control cable back to the welding generator. |
| | Electrode Hot - Stick | Stick welding with or without a remote amperage control. Strike an arc to start welding. |
| | Electrode Hot – TIG Lift Arc | Lift Arc TIG: touch tungsten to work and lift to start welding. Uses circuitry internal to the welding generator to aid arc start. Can be used with or without a remote control. |
| REMOTE ON/OFF REQUIRED | Remote ON/OFF Required - TIG | High Frequency TIG or Scratch Start TIG welding. High frequency TIG starting with remote foot control allows remote On/Off and Amperage control. Another typical application is a simple TIG rig with a remote control device. |
| | Remote On/Off Required - Stick | Stick welding with RFC-14 control allows remote On/Off and Amperage control. This can help eliminate accidental arc strikes. |
| | Remote On/Off Required - FCAW | FCAW using a constant speed feeder. Use feeders with remote voltage control, or use a Spoolmatic 30A with WC 24 control. |
| | Remote On/Off Required - MIG | MIG solid wire using a constant speed feeder. Use feeders with remote voltage control, or use a Spoolmatic 30A with WC 24 control. |

6-4. Arc Control



1 Arc Control

Stick

Control adjusts Dig when Stick is selected on mode switch.

When control is set toward minimum, short-circuit amperage at low arc voltage is the same as normal welding amperage.

When set toward maximum, short-circuit amperage is increased at low arc voltage to help prevent the electrode from sticking while welding (see volt-ampere curves in Section 4-4).

Select setting best suited for application.

FCAW/MIG

Control adjusts inductance when FCAW or MIG position is selected on the mode switch. Inductance determines the “wetness” of the weld puddle. Increasing Arc Control setting decreases inductance, thereby increasing puddle fluidity (“wetness”). Decreasing Arc Control setting increases inductance, decreasing puddle fluidity.

TIG

When the control is set below 1, Auto Stop is a variable function of pre-set weld amperage. This is used with a short arc length where flare at arc shutdown cannot be tolerated.


When the control is set above 1, Auto Stop voltage threshold is a set value based on pre-set weld amperage (I) as follows:

$I \leq 50 \text{ A}, V=17$
 $I > 50 \text{ to } \leq 100 \text{ A}, V=22$
 $I > 100 \text{ to } \leq 190 \text{ A}, V=25$
 $I > 190 \text{ A}, V=30$

This allows for a longer arc length (such as when “walking the cup”), where nuisance shutdowns are undesirable.

Control is not functional when TIG Remote mode is selected.


Suggested Arc Control Settings




STICK MODE

EXX10: **6.5**
Cellulosic Electrodes

EXX18: **2**
Low Hydrogen Electrodes




ARC CONTROL




FCAW MODE

FCAW-G: **4**
Gas-Shielded Flux Core

FCAW-S: **10**
Self-Shielded Flux Core




ARC CONTROL




MIG MODE

Solid Wire: **5**




ARC CONTROL



TIG MODE

“Walking the Cup Method”: **2**


Other Methods: **0**



ARC CONTROL


257145-A

6-5. Low Open-Circuit Voltage (VRD) Switch




1 Voltage Reducing Device (VRD) Switch

The VRD switch can be set for low open-circuit voltage operation in Stick mode. When the unit is configured for low open-circuit voltage operation only a low sensing voltage (approximately 15 volts DC) is present between the electrode and workpiece prior to the electrode touching the workpiece.



907 520-15


6-6. Stick Start Procedure – Scratch Start Technique



With Stick selected, start arc as follows:


- 1 Electrode
- 2 Workpiece
- 3 Arc

Drag electrode across workpiece like striking a match; lift electrode slightly after touching work. If arc goes out electrode was lifted to high. If electrode sticks to workpiece, use a quick twist to free it.



VRD Model Only: Normal open-circuit voltage is not present before electrode touches workpiece; only a low sensing voltage is present between electrode and workpiece. This allows electrode to touch workpiece without overheating, sticking, or getting contaminated.

6-8. Remote Voltage/Amperage Control



1 Remote 14 Receptacle

Connect optional remote control to receptacle (see Section 5-17).

When a remote control is connected to the Remote receptacle, the Auto Sense Remote feature automatically switches voltage/amperage control to the remote control. When a device is connected to the Remote receptacle, remote voltage/amperage control is always available regardless of the position of the Process/Contactor switch.

2 Voltmeter

3 Ammeter

CC Welding


In Example:
Min = 20 A DC
Max = 205 A DC

Voltmeter Shows Open-Circuit Voltage When Not Welding, Arc Voltage While Welding

85


205

Ammeter Shows Preset Output When Not Welding, Actual Amperage While Welding




REMOTE

Connect Remote Control To Remote Receptacle RC14



Set TIG or STICK Process



Turn Remote Control On. Adjust Optional Remote Control to 100%



Set V/A Control To Desired Maximum Weld Output Using Weld Meters

CV Welding

Voltmeter Toggles Between Preset And Actual Output When Not Welding, Actual Voltage While Welding

28


0

Ammeter Shows Zero

Max (205 A DC)


Min (20 A DC)

Adjust Optional Remote Control to desired weld output




REMOTE

Connect Remote Control To Remote Receptacle RC14















Set WIRE Process



Adjust Optional Remote Control to desired weld output


6-10. Fuel/Hour Gauge Descriptions

| FUEL/HOUR GAUGE DESCRIPTIONS | |
|-------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>ENGINE HOURS: Gauge will display engine hours while engine is running. To display engine hours while the engine is off, place Engine Control switch in position “3”.</p>  |
|  | <p>OIL CHANGE INTERVAL: Gauge will display hours remaining before oil change is due with Engine Control switch in position “2” (with engine off).</p>  |
|  | <p>OIL CHANGE DUE: Gauge will display blinking wrench when oil change is due (0 to -99 hours).</p> <p>To Reset: Toggle Engine Control switch between position “2” and “3” three times within 5 seconds (engine off).</p>  |
|  | <p>LOW FUEL PREWARNING: Fault indicator flashes when fuel level reaches 2 bars. Flashing rate increases as fuel level drops.</p> <p>LOW FUEL: Fuel level low when fuel icon and last bar in fuel gauge blink.</p> <p>To Reset: Refuel.</p> |
|  | <p>NO FUEL: Engine shuts down before fuel runs out. Display shows “noFUEL”, and fuel icon and fault indicator flash.</p> <p>To Reset: Refuel.</p> |
|  | <p>LOW OIL PRESSURE: Engine shuts down when oil pressure is low. Display shows “LO OIL”, fault indicator flashes and wrench is displayed.</p> <p>To Reset: Place Engine Control switch in OFF position.</p>  |
|  | <p>HIGH COOLANT TEMP: Engine shuts down when coolant temperature is high. Display shows “HI H2O” and fault indicator flashes.</p> <p>To Reset: Place Engine Control switch in OFF position.</p>  |
| <p>Note: Switch positions are numbered to illustrate that there are four switch positions. Actual graphics on front panel will vary.</p> | |

298 650-B

SECTION 7 – OPERATING AUXILIARY EQUIPMENT

7-1. North American Auxiliary Power Receptacles



251 249-A / 248 894-A

Single-Phase Generator Power

- ⚠ Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacles to power life support equipment.**

- ⚠ Unplug power cord before attempting to service accessories or tools.**

- 1 120 V 20 A AC GFCI Receptacle GFCI1 or GFCI2

- ⚠ Test GFCI monthly. See Section 7-3 for GFCI information and for resetting and testing procedures.**

- 2 240 V 30 A AC Twistlock Receptacle RC1 or RC2

Receptacles supply 60 Hz single-phase power at weld/power speed.

- 3 Supplementary Protector CB6
- 4 Supplementary Protector CB7
- 5 Supplementary Protector CB8

CB6 protects RC1 and RC2, and the generator winding from overload. If CB6 opens, RC1, RC2, GFCI1 and GFCI2 do not work. Place switch in On position to reset.

CB7 protects GFCI1 from overload. If CB7 opens, GFCI1 does not work. Press button to reset.

CB8 protects GFCI2 from overload. If CB8 opens, GFCI2 does not work. Press button to reset.

⚠ If a supplementary protector continues to open, contact Factory Authorized Service Agent.

⚠ Generator power is not affected by weld output.

Maximum output is 2.4 kVA/kW from GFCI1 and 4 kVA/kW from RC1. Maximum output from all receptacles is 4 kVA/kW.

EXAMPLE: If 13 A is drawn from RC1, only 7 A is available at GFCI1:

$$(240 \text{ V} \times 13 \text{ A}) + (120 \text{ V} \times 7 \text{ A}) = 4.0 \text{ kVA/kW}$$

- 6 120/240 V 50 A Receptacle RC5

RC5 is connected to the three-phase generator and supplies 60 Hz single-phase power at weld/power speed. Maximum output from RC5 is 12 kVA/kW. Power available at RC5 is reduced when welding.

Three-Phase Generator Power


- 7 240 V 50 A Three-Phase Receptacle RC4

RC4 is connected to the three-phase generator and supplies 60 Hz three-phase power at weld/power speed. Maximum output from RC4 is 20 kVA/kW. Power available at RC4 is reduced when welding.

- 8 Supplementary Protector CB1

Supplementary protector CB1 protects three-phase receptacle RC4, single-phase receptacle RC5, and the load wires from overload. If CB1 opens, all generator output stops and the receptacles do not work.

7-2. Export Auxiliary Power Receptacles



Ref. 251 252-A / 251 965-A

1 110 V 16 A AC Receptacle RC1

2 220 V 16 A AC Receptacle RC3

Receptacles supply 50/60 Hz single-phase power.

3 Supplementary Protector CB7

CB7 protects GFCI1 and RC1 from overload. If supplementary protector opens, the receptacles do not work. Press button to reset.

⚠ Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacles to power life support equipment.

⚠ Unplug power cord before attempting to service accessories or tools.

4 110 V 20 A AC Receptacle GFCI1

5 110 V 20 A AC Receptacle GFCI2

⚠ Test GFCI monthly. See Section 7-3 for GFCI information and for resetting and testing procedures.

6 Supplementary Protector CB1 (Deluxe Model)

CB1 protects RC5 from overload. If supplementary protector opens, the receptacle does not work. Place switch in On position to reset.

7 380 V 30 A 3-Phase Receptacle RC5 (Deluxe Model)

Receptacle supplies 50/60 Hz three-phase power

8 Supplementary Protector CB5

CB5 protects the auxiliary power winding from over current. If CB5 opens, the 110 volt receptacles and 220 volt receptacles do not work. Press button to reset.

9 Earth Leakage Circuit Breaker ELCB1

ELCB1 protects receptacles RC3 and RC4 from overload and earth leakage fault. If circuit breaker opens, the receptacles do not work. Place switch in On position to reset circuit breaker.

10 Supplementary Protector CB8

CB8 protects GFCI2 and RC2 from overload. If supplementary protector opens, the receptacles do not work. Press button to reset.

11 220 V 16 A AC Receptacle RC4

12 110 V 16 A AC Receptacle RC2

Receptacles supply 50/60 Hz single-phase power.



Maximum combined output of all standard receptacles is 4 kVa/kW.

☞ At least once a month, run engine at weld/power speed and press test button to verify ELCB1 is working properly.

☞ If a supplementary protector or circuit breaker continues to open, contact Factory Authorized Service Agent.

☞ Generator power decreases as weld output increases.

7-3. GFCI Receptacle Information, Resetting And Testing



⚠ Test and reset GFCI only at Run speed.

RotGFCI1 2012-05

⚠ Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacle to power life support equipment.

⚠ Unplug power cord before attempting to service accessories or tools.

- 1 120 V 20 A AC GFCI Receptacle
- 2 GFCI Receptacle Test Button
- 3 GFCI Receptacle Reset Button
- 4 GFCI Indicator Light (LED)

GFCI Receptacles

GFCI receptacles protect the user from electric shock if a ground fault occurs in equipment connected to the receptacle. A ground fault occurs when electrical current takes the shortest path to ground (which could be through a person) rather than follow its intended safe path.

If a ground fault is detected, the GFCI Reset button pops out, and the circuit opens to disconnect power to the faulty equipment. A GFCI receptacle does not protect against circuit overloads, short circuits, or shocks not related to ground faults. Reset and test GFCI receptacle according to the following procedures.

Resetting/Testing GFCI Receptacle

- ⚠ Test GFCI monthly. See Testing GFCI Receptacle.**
- ⚠ Do not test or reset GFCI receptacles at idle speed/low voltage or the GFCI will be damaged and not provide protection from electric shock caused by a ground fault.**
- ⚠ If LED blinks, stop using GFCI receptacle and have it replaced by a Factory Authorized Service Agent.**

Resetting GFCI Receptacles

If a GFCI fault occurs, stop engine and disconnect equipment from GFCI receptacle.

Check for damaged or wet tools, cords, plugs, etc. connected to the receptacle. Start engine and operate at Run (weld/power) speed. Press GFCI Reset button. Reconnect equipment to GFCI receptacle. If GFCI Reset button pops out again, check the equipment and repair or replace if faulty.

Testing GFCI Receptacles

ⓘ *GFCI testing must be done with engine running at Run (weld/power) speed.*

Start engine and operate at Run (weld/power) speed.

Press the GFCI Test button. The GFCI Reset button should pop out.

Press the GFCI Reset button.

Have GFCI replaced by a Factory Authorized Service Agent if any of the following occur:

GFCI does not trip when tested
LED blinks
GFCI does not reset.

SECTION 8 – MAINTENANCE & TROUBLESHOOTING

8-1. Maintenance Label



DEUTZ Service:

<http://www.deutzamericas.com>

To ensure rapid, efficient service support, you should initially contact your nearest DEUTZ service distributor or dealer: <http://www.deutzamericas.com/deutznew/distributors/index.htm>.

They are staffed with highly qualified parts, service and engine specialists to handle your different needs.























The DEUTZ Service Desk enhances this support and can be contacted by completing and submitting the Service Support Form. Customer in the US and CANADA can also contact the service desk by calling our toll free number, 1-800-241-9886.

Our normal hours of operation are from 8:00 AM to 6:00 PM Monday through Friday EST. You may contact our on call service 24 hours, 7 days a week. We ask that when you contact us, please have available or provide specific engine information (serial number, model number etc.) as shown on the Service Support Form.

| | | | | | | | | | | | | | | | |
|-----------------------------------------------------------------------------------------------|--|-------------------------------------------------------------------------------------------------------------------------------------------------------------|--|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|----------------------------------------------------------|--|
| <p>DEUTZ D2011L04(46.9 HP) / D2011L03i(31.9 HP) AND F3L912(41.5 HP) DIESEL ENGINES</p> | | <p>100 h std.</p> <p>(Optional) MILLER 192 939 Donaldson P822769 WIX 46490</p> <p>MILLER 192 938 Donaldson P822768 WIX 46489</p> | | <p>250 h std.</p> <p>1000 h std. 500 h std.</p> <p>API: CD/CE/CF-4</p> <p>D2011L03iD2011L04iF3L912 8.2 L (8.7 qt) 8.5 L (9 qt) 8.5 L (9 qt)</p> <p>D2011L03/4i F3L912 MILLER 067 265 MILLER 249 605 Deutz 117-4416 Deutz 118-2001 Fram PH46 Fram PH6923</p> | | <p>250 h std.</p> <p>1. MILLER 192 744 Donaldson P550587 Fram P1145A</p> <p>2. D2011L03/4i MILLER 066 217 Deutz 117-4896 Donaldson P550345</p> | | <p>3000 h std.</p> <p>13 mm (1/2 in)</p> <p>F3L912 MILLER 066 271 Deutz 223-8256 Gates 7580</p> <p>D2011L04 MILLER 216 959 Deutz 117-9564 Gates 7440</p> <p>D2011L03/4i D912L03 1000 h std. 500 h std.</p> <p>20° C (72° F)</p> <p>D2011L03/4i F3L912 in.-0.3 mm in.-0.15 mm (0.012 in) (0.006 in) ex.-0.5 mm ex.-0.15 mm (0.020 in) (0.006 in)</p> | | <p>8 h std.</p> <p>12 V BCI 24 650 A @ -18C (0F)</p> <p>FILTER KITS: D2011 KIT 246988 D912 KIT 246989</p> <p>DIESEL 93.7 L (24.75 gal)</p> <p>DIN 51 601 BS 2869: A1, A2 ASTM D 975-81: 1-D, 2-D VM-F 800C: DF-A, DF-1, DF-2 S < = .5%</p> | | <p>1000 h std.</p> <p>1. MILLER 192 744 Donaldson P550587 Fram P1145A</p> <p>2. D2011L03/4i MILLER 066 217 Deutz 117-4896 Donaldson P550345</p> | | <p>6000 h / 5 yr std.</p> <p>D2011L03/4i Only</p> | |
| <p>DEUTZ D2011L04(46.9 HP) / D2011L03i(31.9 HP) AND F3L912(41.5 HP) DIESEL ENGINES</p> | | <p>100 h std.</p> <p>(Optional) MILLER 192 939 Donaldson P822769 WIX 46490</p> <p>MILLER 192 938 Donaldson P822768 WIX 46489</p> | | <p>250 h std.</p> <p>1000 h std. 500 h std.</p> <p>API: CD/CE/CF-4</p> <p>D2011L03iD2011L04iF3L912 8.2 L (8.7 qt) 8.5 L (9 qt) 8.5 L (9 qt)</p> <p>D2011L03/4i F3L912 MILLER 067 265 MILLER 249 605 Deutz 117-4416 Deutz 118-2001 Fram PH46 Fram PH6923</p> | | <p>250 h std.</p> <p>1. MILLER 192 744 Donaldson P550587 Fram P1145A</p> <p>2. D2011L03/4i MILLER 066 217 Deutz 117-4896 Donaldson P550345</p> | | <p>3000 h std.</p> <p>13 mm (1/2 in)</p> <p>F3L912 MILLER 066 271 Deutz 223-8256 Gates 7580</p> <p>D2011L04 MILLER 216 959 Deutz 117-9564 Gates 7440</p> <p>D2011L03/4i D912L03 1000 h std. 500 h std.</p> <p>20° C (72° F)</p> <p>D2011L03/4i F3L912 in.-0.3 mm in.-0.15 mm (0.012 in) (0.006 in) ex.-0.5 mm ex.-0.15 mm (0.020 in) (0.006 in)</p> | | <p>8 h std.</p> <p>12 V BCI 24 650 A @ -18C (0F)</p> <p>FILTER KITS: D2011 KIT 246988 D912 KIT 246989</p> <p>DIESEL 93.7 L (24.75 gal)</p> <p>DIN 51 601 BS 2869: A1, A2 ASTM D 975-81: 1-D, 2-D VM-F 800C: DF-A, DF-1, DF-2 S < = .5%</p> | | <p>1000 h std.</p> <p>1. MILLER 192 744 Donaldson P550587 Fram P1145A</p> <p>2. D2011L03/4i MILLER 066 217 Deutz 117-4896 Donaldson P550345</p> | | <p>6000 h / 5 yr std.</p> <p>D2011L03/4i Only</p> | |

8-2. Routine Maintenance

| | | | | | | | | |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |  |  |  |  |  |  Recycle engine fluids. |  Stop engine before maintaining. |  <i>See Engine Manual and Maintenance Label for important start-up, service, and storage information. Service engine more often if used in severe conditions.</i> |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| |  | ✓ = Check ◇ = Change ● = Clean * To be done by Factory Authorized Service Agent | ☆ = Replace | | Reference |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|------------------------------------|
| Every 8 Hours |  ✓ Fuel/Water Separator |  ✓ Fuel Level |  ✓ Oil Level |  ● Oil, Fuel Spills | Section 5-7, 8-5 |
| Every 50 Hours |  ● Weld Terminals | | | | |
| Every 100 Hours |  ● Battery Terminals |  ✓ Air Cleaner Hoses |  ✓ Air Cleaner Element | | Section 8-4 |
| Every 250 Hours |  ☆ Unreadable Labels |  ✓ Fan Belt Tension |  ● Cooling System |  ✓ ● Spark Arrestor | Engine Manual |
| Every 500 Hours |  ✓ ☆ Weld Cables | | | | |
| Every 1000 Hours | NOTICE - Change engine oil and filter after initial 50 to 75 hours of use.  ◇ Oil ◇ Oil Filter |  ◇ Fuel Filter | | | Section 8-5, 8-3 and Engine Manual |
| |  ✓ ● Slip Rings* ✓ ☆ Brushes* |  ● Inside Unit |  ✓ Valve Clearance* |  ● Drain Sludge | |
| Every 3000 Hours |  ● Injectors* | | | | |
| Every 6000 Hours or 5 Years |  ✓ ☆ Engine Timing Belt | | | | |

● = Clean unit exterior, including stainless steel, frequently to prevent rust and corrosion.

8-3. Checking Generator Brushes




⚠ Stop engine and let cool.

1 Generator Brush

Mark and disconnect leads at brush holder cap. Remove brushes.


Replace brushes if damaged or if brush material is at or near minimum length.




GenBrush1 2012-05 / Ref 190 823

Notes


8-4. Servicing Air Cleaner




☞ Unlatch dust cover, allow it to drop. Remove primary element. Dust cover can then be removed for cleaning.



☞ Keep nozzle 2 in. (51 mm) from element.



Blow



Inspect

aircleaner1 2011-08- ST-153 929-B / ST-153 585 / Ref. S-0698-B

⚠ Stop engine.

NOTICE – Do not run engine without air cleaner or with dirty element. Engine damage caused by using a damaged element is not covered by the warranty.

☞ The air cleaner primary element can be cleaned but the dirt holding capacity of the filter is reduced with each cleaning. The chance of dirt reaching the clean side of the filter while cleaning and the possibility of filter damage makes cleaning a risk. Consider the risk of unwarrantable equipment damage when determining whether to clean or replace the primary element.

If you decide to clean the primary element, we strongly recommend in-

stalling an optional safety element to provide additional engine protection. **Never clean a safety element.** Replace the safety element after servicing the primary element three times.

Clean or replace primary element if dirty (see note above before cleaning). **Replace** primary element if damaged. Replace primary element yearly or after six cleanings.

- 2 Housing
- 3 Safety Element (Optional)
- 4 Primary Element
- 5 Cover
- 6 Dust Ejector

To clean air filter:

Wipe off cover and housing. Remove cover and dump out dust. Remove element(s). Wipe dust from inside cover and housing with damp cloth. Reinstall safety element (if present). Reinstall cover.

NOTICE – Do not clean housing with air hose.

Clean primary element with compressed air only.




Air pressure must not exceed 100 psi (690 kPa). Use 1/8 in. (3 mm) nozzle and keep nozzle at least 2 in. (51 mm) from inside of element. Replace primary element if it has holes or damaged gaskets.

Reinstall primary element and cover (dust ejector down).


8-5. Adjusting Engine Speed



| | |
|--|--------------------------|
| | |
| | 1860 rpm Max. (62 Hz) |
| | 1350 rpm (45 Hz) |



Tools Needed:



Stop engine and let cool.

For operation at high altitude, engine may require adjustment. If adjustment is necessary, contact engine manufacturer's Factory Authorized Service Agent.

Engine speed is factory set and should not require adjustment. After tuning engine, check engine no load speed with a tachometer or frequency meter (see table for no load speeds). If necessary, adjust speed as follows:

Start engine and run until warm.

Turn Process/Contactor switch to Stick – Electrode Hot position.

- 1 Throttle Rod
- 2 Locknut
- 3 Throttle Stop Screw
- 4 Throttle Lever

Loosen locknuts. Place engine control switch in Run/Idle position.

Turn throttle rod until engine runs at idle speed. Tighten locknuts.

NOTICE – To prevent solenoid damage, be sure a 1/8 in. (3 mm) gap exists between the throttle stop screw and throttle lever when the solenoid is held in the energized position.

- 5 Engine Speed Adjustment Screw
- 6 Locknut

Place engine control switch in Run position.


Loosen locknut. Turn screw until engine runs at weld/power speed. Tighten locknut.

Do not set engine speed higher than specified.

Stop engine.

Close door.

8-6. Servicing Fuel And Lubrication Systems



907 520-4

⚠ Stop engine and let cool.

⚠ After servicing, start engine and check for fuel leaks. Stop engine, tighten connections as necessary, and wipe up spilled fuel.

- 1 Oil Filter
- 2 Oil Drain Valve And Hose
- 3 Oil Fill Cap
- 4 Primary Fuel Filter (Fuel/Water Separator)
- 5 Petcock
- 6 Secondary Fuel Filter
- 7 Fuel Tank Sludge Drain Valve

To change oil and filter:

Route oil drain hose and valve through hole

in base. See engine manual and engine maintenance label for oil/filter change information.

To drain water from fuel system:

Open primary fuel filter petcock and drain water into metal container. Close petcock when water-free fuel flows.

To replace primary fuel filter:

Turn filter counterclockwise. Remove filter.

Apply thin coat of fuel to gasket on new filter. Fill filter with fuel. Install filter and turn clockwise. Bleed air from fuel system according to engine manual.

Inspect fuel line, and replace if cracked or worn.

To replace secondary fuel filter:

See engine manual.

Close doors.




To drain sludge from fuel tank:

⚠ Beware of fire. Do not smoke and keep sparks and flames away from drained fuel. Dispose of drained fuel in an environmentally-safe manner. Do not leave unit unattended while draining fuel tank.

⚠ Properly lift unit and secure in a level position. Use adequate blocks or stands to support unit while draining fuel tank.

Attach 1/2 ID hose to drain valve. Put metal container under drain, and use screwdriver to open sludge drain valve. Close valve when sludge has drained. Remove hose.

8-7. Overload Protection



Stop engine.

When a supplementary protector, circuit breaker or fuse opens, it usually indicates a more serious problem exists. Contact Factory Authorized Service Agent.

- 1 Fuse F1
- 2 Fuse F2

F1 and F2 protect the stator exciter winding from overload. If F1 opens, weld and generator power is low or stops entirely. If F2 opens, weld output is low or stops entirely. 4 kVA/kW generator power is still available.

- 3 Supplementary Protector CB9
- 4 Supplementary Protector CB29
- 5 Circuit Breaker CB10 (Not Shown)
- 6 Supplementary Protector CB2
- 7 Supplementary Protector CB3
- 8 Supplementary Protector CB4
- 9 Circuit Breaker CB14 (Not Shown)

CB9 and CB29 protect the 24 volt AC output to remote receptacles, and 24 volt output to field current regulator board PC?. If CB opens, weld output and 24 volt output to remote receptacle stops.

CB10 protects the engine battery circuit. If CB10 opens, the engine will not crank. CB10 automatically resets when the fault is corrected.



CB2 protects the engine control circuit. If CB2 opens, the engine does not crank.

CB3 protects the engine weld control circuit. If CB3 opens, weld output stops, meters will be blank; however, generator power is still available.



CB4 protects the field flashing circuit. If CB4 opens, the generator may not excite at start-up and weld and generator power output may not be available.

CB14 protects throttle solenoid TS1. If CB14 opens, the engine does not run at idle speed. CB14 automatically resets when the fault is corrected.

Press button to reset.



8-8. Voltmeter/Ammeter Help Displays



Use the Voltmeter/Ammeter help displays to diagnose and correct fault conditions.

When a help code is displayed normally weld output has stopped but generator power output may be okay.

To reset help displays, stop unit and then restart. See item 4 below to reset Help 25 display.

1 Help 20 Display

Indicates a failure of meter display module PC2/PC22, or the wiring between PC2/PC22 and main control module PC1 (A Side)/PC3 (B Side), or PC1/PC3. If this display is shown, have Factory Authorized Service Agent check PC1/PC3, PC2/PC22, and the wiring between them.

2 Help 21 Display

Thermistor TH1 in the IGBT module (each

side) on the heat sink has failed. If this display is shown, have Factory Authorized Service Agent check TH1 (each side), and the wiring between TH1 and PC1/PC3.

3 Help 22 Display

Indicates the IGBT module heat sink (each side) has overheated. If this display is shown, check generator cooling system and/or reduce duty cycle. Keep engine access door closed when running to maintain proper cooling air flow past the heat sinks. Allow unit to cool before restarting. If problem continues, have Factory Authorized Service Agent check unit.

4 Help 25 Display


Indicates a remote device connected to Remote Receptacle RC14 may be faulty. Help 25 is also displayed whenever a remote device has been connected to RC14

and then disconnected. Clear fault by stopping and restarting the unit or by turning Process/Contactor switch to another position. If problem continues, have Factory Authorized Service Agent check the remote device, filter board PC5/PC25, and main control module PC1/PC3.

5 Help 26 Display

Indicates a fault when attempting to operate the unit in single operator mode (outputs internally paralleled). Help 26 indicates a failure of either side A or side B or the communications between them which prevents the unit from being operated in the single operator mode. Return to dual operator mode and check for output at both sides. If output is normal, contact Factory Authorized Service Agent to check internal wiring and communications between sides.

8-9. Troubleshooting



☞ Also see Voltmeter/Ammeter help displays to assist in troubleshooting weld problems (see Section 8-8).

A. Welding

| Trouble | Remedy |
|----------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No weld output; generator power output okay at AC receptacles. | Place Process/Contactor switch in an Electrode Hot position, or place switch in a Remote On/Off Required position and connect remote contactor to Remote 14 receptacle (see Sections 5-17). |
| | Reset supplementary protector CB3 (see Section 8-7). |
| | Reset supplementary protector CB9 and/or CB29 (see Section 8-7). Check for faulty remote device connected to Remote 14 receptacle. |
| | Check and secure connections to Remote 14 receptacle (see Section 5-17). |
| | Have Factory Authorized Service Agent check filter board PC5 and/or PC25 and connections. |
| No weld output or generator power output at AC receptacles. | Disconnect equipment from generator power receptacles during start-up. |
| | Reset supplementary protector CB4. |
| | Check fuses F1 and F2, and replace if open (see Section 8-7). Have Factory Authorized Service Agent check integrated rectifier SR2, capacitor C6, field current regulator board, and the rotor. |
| | Have Factory Authorized Service Agent check brushes and slip rings, and field excitation circuit. |
| Erratic weld output. | Check and tighten connections inside and outside unit. |
| | Be sure connection to work piece is clean and tight. |
| | Use dry, properly stored electrodes. |
| | Remove excessive coils from weld cables. |
| High weld output. | Check position of Voltage/Amperage Adjust control. |
| | Check engine speed, and adjust if necessary. |
| | Have Factory Authorized Service Agent check field current regulator board, and voltage feedback circuit. |
| Low weld output. | Check position of Voltage/Amperage Adjust control. |
| | Check engine speed, and adjust if necessary. |
| | Check fuses F1 and F2, and replace if open (see Section 8-7). Have Factory Authorized Service Agent check integrated rectifier SR2, capacitor C6, field current regulator board, and the rotor. |
| Low open-circuit voltage. | Check engine speed, and adjust if necessary. |
| | Check position of Process/Contactor switch. |
| No remote fine amperage or voltage control. | Check and secure connections to Remote 14 receptacle (see Section 5-17). |
| | Repair or replace remote control device. |
| | Have Factory Authorized Service Agent check current sensing devices, and connections. |
| Constant speed wire feeder does not work. | Reset supplementary protector CB9 or CB29 (see Section 8-7). |
| | Check and secure connections to Remote 14 receptacle (see Section 5-17). |
| | Repair or replace wire feeder. |
| Low CV weld output. | Increase Voltage/Amperage Adjust Control setting. |

| Trouble | Remedy |
|---------------------------------|----------------------------------------------------------------------------------------------------------------|
| Min or max CV weld output only. | Check position of Voltage/Amperage Adjust control and Process/Contactor switch. |
| | Repair or replace remote control device. |
| | Have Factory Authorized Service Agent check Amperage/Voltage Adjust Control and field current regulator board. |

B. Standard Generator Power

| Trouble | Remedy |
|----------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No generator power output at AC receptacles; weld output okay. | Reset receptacle supplementary protectors. Reset GFCI receptacle. |
| | Check fuse F1, and replace if open (see Section 8-7). Have Factory Authorized Service Agent check integrated rectifiers SR1 and SR2, resistor R3, and capacitor C6. |
| No generator power or weld output. | Disconnect equipment from generator power receptacles during start-up. |
| | Check fuses F1 and F2, and replace if open (see Section 8-7). Have Factory Authorized Service Agent check integrated rectifiers SR1 and SR2, capacitor C6, and the rotor. |
| | Reset supplementary protector CB4. Have Factory Authorized Service Agent check integrated rectifier SR1 . |
| | Have Factory Authorized Service Agent check brushes and slip rings, and field excitation circuit. |
| High output at generator power AC receptacles. | Check engine speed, and adjust if necessary. |
| | Have Factory Authorized Service Agent adjust generator power field current resistor R3. |
| Low output at generator power AC receptacles. | Check engine speed, and adjust if necessary. |
| | Check fuse F1, and replace if open (see Section 8-7). Have Factory Authorized Service Agent check integrated rectifier SR2, resistor R3, and capacitor C6. |
| | Have Factory Authorized Service Agent check brushes and slip rings, and field current regulator board. |

C. Three-Phase Generator Power

| Trouble | Remedy |
|-----------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
| No or low output at three-phase generator/receptacle RC5. | Reset supplementary protector CB1 (see Section 8-7). |
| | Check engine weld/power speed, and adjust if necessary (see Section 8-5). |
| | Have Factory Authorized Service Agent check brushes and slip rings, and field current regulator board. |
| High output at three-phase generator/receptacle RC5. | Check engine weld/power speed, and adjust if necessary (see Section 8-5). |
| | Have Factory Authorized Service Agent check field current regulator board. |
| Erratic output at three-phase generator/receptacle RC5. | Have Factory Authorized Service Agent check brushes and slip rings, and field current regulator board. |

D. Engine

| Trouble | Remedy |
|------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Engine will not crank. | Supplementary protector CB2 open. Reset CB2. |
| | Check battery connections and tighten if necessary. Check battery, and replace if necessary. |
| | Circuit breaker CB10 may be open. CB10 automatically resets when fault is corrected (see Section 8-7). Have Factory Authorized Service Agent check engine wiring harness and components. |
| | Check engine wiring harness plug connections. |
| | Have Factory Authorized Service Agent check fuel/hour gauge, control relay CR5 and Engine Control switch S1. |
| Engine cranks but does not start. | Check fuel level. |
| | Check battery and replace if necessary. Check engine charging system according to engine manual. |
| | Have Factory Authorized Service Agent check fuel/hour gauge, control relay CR5, fuel pump, and fuel solenoid FS1. |
| | Air in fuel system. See engine manual. |
| Engine starts, but stops when Engine Control switch is released. | Check oil level. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high (see Section 5-7). Automatic shutdown system is inhibited for 30 seconds after start-up. |
| | Have Factory Authorized Service Agent check fuel/hour gauge, and control relay CR5. |
| Engine hard to start in cold weather. | Use starting aid switch (see Section 6-2). |
| | Keep battery in good condition. Store battery in warm area off cold surface. |
| | Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information. |
| | Use correct grade oil for cold weather (see Section 8-1). |
| Engine suddenly stops. | Check oil level. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high (see Section 5-7). Automatic shutdown system is inhibited for 30 seconds after start-up. |
| | See engine manual. |
| Engine slowly stopped and cannot be restarted. | Check fuel level. |
| | Check engine air and fuel filters (see Sections 8-4 and 8-6). |
| | See engine manual. |
| Battery discharges between uses. | Turn Engine Control switch off when unit is not running. |
| | Clean top of battery with baking soda and water solution; rinse with clear water. |
| | Recharge or replace battery if necessary. |
| | Periodically recharge battery (approximately every 3 months). |
| Engine idles, but does not come up to weld speed. | Have Factory Authorized Service Agent check current transformer CT1 and main control board PC1. |
| | Check for obstructed throttle solenoid. |
| Engine does not run at idle speed. | Circuit breaker CB14 may be open. CB14 automatically resets when fault is corrected (see Section 8-7). Check for obstructed throttle solenoid. Have Factory Authorized Service Agent check TS1. |
| | Have Factory Authorized Service Agent check control relays CR3 and CR4. |
| Engine uses oil during run-in period; wetstacking occurs. | Dry engine according to run-in procedure (see Section 10). |

SECTION 9 - ELECTRICAL DIAGRAMS





Figure 9-1. Circuit Diagram For Export Welding Generator




- S1 POSITION/MODE
- OFF
 - RUN
 - RUN/IDLE
 - START
- (VIEWED FROM WIRE SIDE)

WARNING


ELECTRIC SHOCK HAZARD

- Do not touch live electrical parts.
- Disconnect input power or stop engine before servicing.
- Do not operate with covers removed.
- Have only qualified persons install, use, or service this unit.



- S1 POSITION/MODE
- OFF
 - RUN
 - RUN/IDLE
 - START
- (VIEWED FROM WIRE SIDE)


| | |
|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>WARNING</p> <p>ELECTRIC SHOCK HAZARD</p> | <ul style="list-style-type: none"> Do not touch live electrical parts. Disconnect input power or stop engine before servicing. Do not operate with covers removed. Have only qualified persons install, use, or service this unit. |
|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|



SECTION 10 – RUN-IN PROCEDURE

Ref: run_in1 2007-04 Duo Pro

10-1. Wetstacking



NOTICE – Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Welding Generator

Run diesel engines near rated voltage and current during run-in period to properly seat piston rings and prevent wetstacking. See nameplate, rating label, or specifications section in this manual to find rated voltage and current.

NOTICE – Do not idle engine longer than necessary. Piston rings seat faster if engine runs at weld/power rpm, and the welding generator is kept loaded during run-in.


2 Engine Exhaust Pipe

Wetstacking is unburned fuel and oil in the exhaust pipe and occurs during run-in if the engine is run too long at light load or idle rpm.

If exhaust pipe is coated with a wet, black, tar-like substance, dry the engine using one of the following run-in procedures.

See the engine manual for additional engine run-in information.

10-2. Run-In Procedure Using Load Bank



- Stop engine.**
- Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- Keep exhaust and pipe away from flammables.**

NOTICE – Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Load Bank

Turn all load bank switches Off. If needed, connect load bank to 115 volts ac wall receptacle or generator auxiliary power receptacle.

2 Welding Generator

Place Welder Selector switch in the A position (Single Operator) and rotate A/V control to minimum. Place Process Selector switch in Stick position.

3 Weld Cables

Connect load bank to generator Side A weld output terminals using proper size weld cables with correct connectors. Observe correct polarity.

Start engine and run for several minutes.

Set load bank switches and then adjust generator A/V control so load equals rated voltage and current of generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and load bank meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

NOTICE – Check oil level frequently during run-in; add oil if needed.



It is recommended to run the welding generator for two hours minimum and up to four hours under load. Place A/V control in minimum position, then turn off load bank to remove load. Run engine several minutes at no load.

- Stop engine and let cool.**

4 Engine Exhaust Pipe

Repeat procedure if wetstacking is present.

10-3. Run-In Procedure Using Resistance Grid



- Stop engine.**
- Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- Keep exhaust and pipe away from flammables.**

NOTICE – Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Resistance Grid

Use grid sized for generator rated output.

Turn Off grid.

2 Welding Generator

Place Welder Selector switch in the A position (Single Operator) and rotate A/V control to minimum. Place Process Selector switch in Stick position.

3 Weld Cables

Connect grid to generator Side A weld output terminals using proper size weld cables with correct connectors (polarity is not important).

4 Voltmeter

5 Clamp-On Ammeter

Connect voltmeter and ammeter as shown, if not provided on generator.

Start engine and run for several minutes.

Set grid switches and then adjust generator A/V control so load equals rated voltage and current of the generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

NOTICE – Check oil level frequently during run-in; add oil if needed.

It is recommended to run the welding generator for two hours minimum and up to four hours under load. Place A/V control in minimum position, then shut down grid to remove load. Run engine several minutes at no load.

- Stop engine and let cool.**



6 Engine Exhaust Pipe


Repeat procedure if wetstacking is present.

SECTION 11 – GENERATOR POWER GUIDELINES

The views in this section are intended to be representative of all engine-driven welding generators. Your unit may differ from those shown.

11-1. Selecting Equipment





- 1 Generator Power Receptacles – Neutral Bonded To Frame
- 2 3-Prong Plug From Case Grounded Equipment
- 3 2-Prong Plug From Double Insulated Equipment


Be sure equipment has double insulated symbol and/or wording on it.

Do not use 2-prong plug unless equipment is double insulated.

gen_pwr 2012-03 – ST-800 577

11-2. Grounding Generator To Truck Or Trailer Frame



800 652-D

Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.

Also see AWS Safety & Health Fact Sheet No. 29, Grounding of Portable And Vehicle Mounted Welding Generators.

- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame

Connect cable from equipment ground terminal to metal vehicle frame. Use #8 AWG or larger insulated copper wire.

Electrically bond generator frame to vehicle frame by metal-to-metal contact.

Bed liners, shipping skids, and some running gear insulate the welding generator from the vehicle frame. Always connect a ground wire from the generator equipment grounding terminal to bare metal on the vehicle frame as shown.

Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacles to power life support equipment.

11-3. Grounding When Supplying Building Systems

1 Equipment Grounding Terminal
2 Grounding Cable
Use #8 AWG or larger insulated copper wire.
3 Ground Device

Use ground device as stated in electrical codes.

⚠ Ground generator to system earth ground if supplying power to a premises (home, shop, farm) wiring system.

⚠ Also see AWS Safety & Health Fact Sheet No. 29, Grounding of Portable And Vehicle Mounted Welding Generators.

ST-800 576-B

11-4. How Much Power Does Equipment Require?

1 Resistive Load
A light bulb is a resistive load and requires a constant amount of power.

2 Non-Resistive Load
Equipment with a motor is a non-resistive load and requires approximately six times more power while starting the motor than when running (see Section 11-8).

3 Rating Data
Rating shows volts and amperes, or watts required to run equipment.

Amperes x Volts = Watts

Example 1: If a drill uses 4.5 amperes at 115 volts, calculate its running power requirement in watts.
 $4.5 \text{ A} \times 115 \text{ V} = 520 \text{ W}$
The load applied by the drill is 520 watts.

Example 2: If three 200 watt flood lamps are used with the drill from Example 1, add the individual loads to calculate total load.
 $(3 \times 200\text{W}) + 520 \text{ W} = 1120 \text{ W}$
The total load applied by the three flood lamps and drill is 1120 watts.

S-0623

11-5. Approximate Power Requirements For Industrial Motors

| Industrial Motors | Rating | Starting Watts | Running Watts |
|-------------------------------|----------|----------------|---------------|
| Split Phase | 1/8 HP | 800 | 300 |
| | 1/6 HP | 1225 | 500 |
| | 1/4 HP | 1600 | 600 |
| | 1/3 HP | 2100 | 700 |
| | 1/2 HP | 3175 | 875 |
| Capacitor Start-Induction Run | 1/3 HP | 2020 | 720 |
| | 1/2 HP | 3075 | 975 |
| | 3/4 HP | 4500 | 1400 |
| | 1 HP | 6100 | 1600 |
| | 1-1/2 HP | 8200 | 2200 |
| | 2 HP | 10550 | 2850 |
| | 3 HP | 15900 | 3900 |
| Capacitor Start-Capacitor Run | 5 HP | 23300 | 6800 |
| | 1-1/2 HP | 8100 | 2000 |
| | 5 HP | 23300 | 6000 |
| | 7-1/2 HP | 35000 | 8000 |
| | 10 HP | 46700 | 10700 |
| Fan Duty | 1/8 HP | 1000 | 400 |
| | 1/6 HP | 1400 | 550 |
| | 1/4 HP | 1850 | 650 |
| | 1/3 HP | 2400 | 800 |
| | 1/2 HP | 3500 | 1100 |

11-6. Approximate Power Requirements For Farm/Home Equipment


| Farm/Home Equipment | Rating | Starting Watts | Running Watts |
|----------------------------|----------|----------------|---------------|
| Stock Tank De-Icer | | 1000 | 1000 |
| Grain Cleaner | 1/4 HP | 1650 | 650 |
| Portable Conveyor | 1/2 HP | 3400 | 1000 |
| Grain Elevator | 3/4 HP | 4400 | 1400 |
| Milk Cooler | | 2900 | 1100 |
| Milker (Vacuum Pump) | 2 HP | 10500 | 2800 |
| FARM DUTY MOTORS | 1/3 HP | 1720 | 720 |
| Std. (e.g. Conveyors, | 1/2 HP | 2575 | 975 |
| Feed Augers, Air | 3/4 HP | 4500 | 1400 |
| Compressors) | 1 HP | 6100 | 1600 |
| | 1-1/2 HP | 8200 | 2200 |
| | 2 HP | 10550 | 2850 |
| | 3 HP | 15900 | 3900 |
| | 5 HP | 23300 | 6800 |
| High Torque (e.g. Barn | 1-1/2 HP | 8100 | 2000 |
| Cleaners, Silo Unloaders, | 5 HP | 23300 | 6000 |
| Silo Hoists, Bunk Feeders) | 7-1/2 HP | 35000 | 8000 |
| | 10 HP | 46700 | 10700 |
| 3-1/2 cu. ft. Mixer | 1/2 HP | 3300 | 1000 |
| High Pressure 1.8 Gal/Min | 500 PSI | 3150 | 950 |
| Washer 2 gal/min | 550 PSI | 4500 | 1400 |
| 2 gal/min | 700 PSI | 6100 | 1600 |
| Refrigerator or Freezer | | 3100 | 800 |
| Shallow Well Pump | 1/3 HP | 2150 | 750 |
| | 1/2 HP | 3100 | 1000 |
| Sump Pump | 1/3 HP | 2100 | 800 |
| | 1/2 HP | 3200 | 1050 |

11-7. Approximate Power Requirements For Contractor Equipment

| Contractor | Rating | Starting Watts | Running Watts |
|----------------------|------------------|----------------|---------------|
| Hand Drill | 1/4 in | 350 | 350 |
| | 3/8 in | 400 | 400 |
| | 1/2 in | 600 | 600 |
| Circular Saw | 6-1/2 in | 500 | 500 |
| | 7-1/4 in | 900 | 900 |
| | 8-1/4 in | 1400 | 1400 |
| Table Saw | 9 in | 4500 | 1500 |
| | 10 in | 6300 | 1800 |
| Band Saw | 14 in | 2500 | 1100 |
| Bench Grinder | 6 in | 1720 | 720 |
| | 8 in | 3900 | 1400 |
| | 10 in | 5200 | 1600 |
| Air Compressor | 1/2 HP | 3000 | 1000 |
| | 1 HP | 6000 | 1500 |
| | 1-1/2 HP | 8200 | 2200 |
| | 2 HP | 10500 | 2800 |
| Electric Chain Saw | 1-1/2 HP, 12 in | 1100 | 1100 |
| | 2 HP, 14 in | 1100 | 1100 |
| Electric Trimmer | Standard 9 in | 350 | 350 |
| | Heavy Duty 12 in | 500 | 500 |
| Electric Cultivator | 1/3 HP | 2100 | 700 |
| Elec. Hedge Trimmer | 18 in | 400 | 400 |
| Flood Lights | HID | 125 | 100 |
| | Metal Halide | 313 | 250 |
| | Mercury | 1000 | |
| | Sodium Vapor | 1400 | 1000 |
| Submersible Pump | 400 gph | 600 | 200 |
| Centrifugal Pump | 900 gph | 900 | 500 |
| Floor Polisher | 3/4 HP, 16 in | 4500 | 1400 |
| | 1 HP, 20 in | 6100 | 1600 |
| High Pressure Washer | 1/2 HP | 3150 | 950 |
| | 3/4 HP | 4500 | 1400 |
| | 1 HP | 6100 | 1600 |
| 55 gal Drum Mixer | 1/4 HP | 1900 | 700 |
| Wet & Dry Vac | 1.7 HP | 900 | 900 |
| | 2-1/2 HP | 1300 | 1300 |

11-8. Power Required To Start Motor

| Single-Phase Induction Motor Starting Requirements | | | | | | | | |
|----------------------------------------------------|-----|-----|-----|-----|------|------|------|------|
| Motor Start Code | G | H | J | K | L | M | N | P |
| KVA/HP | 6.3 | 7.1 | 8.0 | 9.0 | 10.0 | 11.2 | 12.5 | 14.0 |



- 1 Motor Start Code
- 2 Running Amperage
- 3 Motor HP
- 4 Motor Voltage

To find starting amperage:

Step 1: Find code and use table to find kVA/HP. If code is not listed, multiply running amperage by six to find starting amperage.

Step 2: Find Motor HP and Volts.

Step 3: Determine starting amperage (see example).

Welding generator amperage output must be at least twice the motor's running amperage.

$$\frac{(kVA/HP \times HP \times 1000)}{\text{Volts}} = \text{Starting Amperage}$$

Example: Calculate starting amperage required for a 230 V, 1/4 HP motor with a motor start code of M.


Volts = 230, HP = 1/4, kVA/HP = 11.2

$$(11.2 \times 1/4 \times 1000) / 230 = 12.2A$$

Starting the motor requires 12.2 amperes.

S-0624

11-9. How Much Power Can Generator Supply?



- 1 Limit Load To 90% Of Generator Output


Always start non-resistive (motor) loads in order from largest to smallest, and add resistive loads last.

- 2 5 Second Rule

If motor does not start within 5 seconds, turn off power to prevent motor damage. Motor requires more power than generator can supply.

Ref. ST-800 396-A / S-0625

11-10. Typical Connections To Supply Standby Power



⚠ Have only qualified persons perform these connections according to all applicable codes and safety practices.

⚠ Properly install, ground, and operate this equipment according to its Owner's Manual and national, state, and local codes.

ⓘ Customer-supplied equipment is required if generator will supply standby power during emergencies or power outages.

1 Utility Electrical Service

2 Transfer Switch (Double-Throw)

Switch transfers the electrical load from electric utility service to the generator. Transfer load back to electric utility when service is restored.

Install correct switch (customer-supplied). Switch rating must be same as or greater than the branch overcurrent protection.

3 Fused Disconnect Switch

Install correct switch (customer-supplied) if required by electrical code.

4 Welding Generator Output

Generator output voltage and wiring must be consistent with regular (utility) system voltage and wiring.


Connect generator with temporary or permanent wiring suitable for the installation.

Turn off or unplug all equipment connected to generator before starting or stopping engine. When starting or stopping, the engine has low speed which causes low voltage and frequency.


5 Essential Loads

Generator output may not meet the electrical requirements of the premises. If generator does not produce enough output to meet all requirements, connect only essential loads (pumps, freezers, heaters, etc. – See Section 11-4).

11-11. Selecting Extension Cord (Use Shortest Cord Possible)


| Cord Lengths for 120 Volt Loads | | | | | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|-------------------------------------------------------------------|-----------|-----------|----------|----------|----------|
|  | | | | | | | |
| ⚠ Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacles to power life support equipment. | | | | | | | |
| Current (Amperes) | Load (Watts) | Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)* | | | | | |
| | | 4 | 6 | 8 | 10 | 12 | 14 |
| 5 | 600 | | | 350 (106) | 225 (68) | 137 (42) | 100 (30) |
| 7 | 840 | | 400 (122) | 250 (76) | 150 (46) | 100 (30) | 62 (19) |
| 10 | 1200 | 400 (122) | 275 (84) | 175 (53) | 112 (34) | 62 (19) | 50 (15) |
| 15 | 1800 | 300 (91) | 175 (53) | 112 (34) | 75 (23) | 37 (11) | 30 (9) |
| 20 | 2400 | 225 (68) | 137 (42) | 87 (26) | 50 (15) | 30 (9) | |
| 25 | 3000 | 175 (53) | 112 (34) | 62 (19) | 37 (11) | | |
| 30 | 3600 | 150 (46) | 87 (26) | 50 (15) | 37 (11) | | |
| 35 | 4200 | 125 (38) | 75 (23) | 50 (15) | | | |
| 40 | 4800 | 112 (34) | 62 (19) | 37 (11) | | | |
| 45 | 5400 | 100 (30) | 62 (19) | | | | |
| 50 | 6000 | 87 (26) | 50 (15) | | | | |


*Conductor size is based on maximum 2% voltage drop

| Cord Lengths for 240 Volt Loads | | | | | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|-------------------------------------------------------------------|-----------|-----------|-----------|----------|----------|
|  | | | | | | | |
| ⚠ Use GFCI protection when operating auxiliary equipment. If unit does not have GFCI receptacles, use GFCI-protected extension cord. Do not use GFCI receptacles to power life support equipment. | | | | | | | |
| Current (Amperes) | Load (Watts) | Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)* | | | | | |
| | | 4 | 6 | 8 | 10 | 12 | 14 |
| 5 | 1200 | | | 700 (213) | 450 (137) | 225 (68) | 200 (61) |
| 7 | 1680 | | 800 (244) | 500 (152) | 300 (91) | 200 (61) | 125 (38) |
| 10 | 2400 | 800 (244) | 550 (168) | 350 (107) | 225 (69) | 125 (38) | 100 (31) |
| 15 | 3600 | 600 (183) | 350 (107) | 225 (69) | 150 (46) | 75 (23) | 60 (18) |
| 20 | 4800 | 450 (137) | 275 (84) | 175 (53) | 100 (31) | 60 (18) | |
| 25 | 6000 | 350 (107) | 225 (69) | 125 (38) | 75 (23) | | |
| 30 | 7000 | 300 (91) | 175 (53) | 100 (31) | 75 (23) | | |
| 35 | 8400 | 250 (76) | 150 (46) | 100 (31) | | | |
| 40 | 9600 | 225 (69) | 125 (38) | 75 (23) | | | |
| 45 | 10,800 | 200 (61) | 125 (38) | | | | |
| 50 | 12,000 | 175 (53) | 100 (31) | | | | |

*Conductor size is based on maximum 2% voltage drop

SECTION 12 – PARTS LIST

 Hardware is common and not available unless listed.



907 520-5

Figure 12-1. Main Assembly – Part 1

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-1. Main Assembly – Part 1

| | | | | |
|-----|----|------------------|---------------------------------------------------|----|
| ... | 1 | | Front Panel see Figure 12-4 thru Figure 12-8 | 1 |
| ... | 2 | 233953 | Label, Warning General Precautionary Csa | 1 |
| ... | 3 | 252490 | Upright, Front | 1 |
| ... | 4 | 189824 | Panel, Generator Lh | 1 |
| ... | 5 | 252811 | Panel, Engine Side | 1 |
| ... | 6 | 191448 | Cover, Top Front Upright | 1 |
| ... | 7 | 252195 | Bracket, Mtg Strip Term 6 Pole | 1 |
| ... | 8 | 172661 | Block, Stud Connection 6 Position | 1 |
| ... | 9 | R10, R210 188067 | Resistor, Ww Fxd 100 W 200 Ohm W/Clips | 2 |
| ... | 10 | 250345 | Pan, Reactor&Rectifier | 1 |
| ... | 11 | | Weld Control Assembly With Vaults see Figure 12-9 | 1 |
| ... | 12 | 201658 | Upright, Center Assy | 1 |
| ... | 13 | 189464 | Seal, Weather Lift Eye | 1 |
| ... | 14 | 206352 | Brace, Front To Center Upright | 2 |
| ... | 15 | 252809 | Firewall, Top | 1 |
| ... | 16 | 218086 | Bracket, Holddown Fuel Tank | 1 |
| ... | 17 | 196220 | Bracket, Holddown Fuel Tank Rear | 1 |
| ... | 18 | 192362 | Bracket, Mtg Nyl 1/2 Conduit | 1 |
| ... | 19 | 173352 | Extrusion, Rubber Clamp/Bulb | ft |
| ... | 20 | 189731 | Firewall, Bottom | 1 |
| ... | 21 | | Control Box Assembly see Figure 12-3 | 1 |
| ... | 22 | 191897 | Bracket, Mtg Unit | 4 |
| ... | 23 | 224266 | Label, Warning Do Not Weld On Base | 2 |
| ... | 24 | 200999 | Base, | 1 |
| ... | 25 | | Label, Rating (Order By Model & Serial No.) | 1 |
| ... | 26 | R3 189699 | Resistor,Ww Tap 375 W 10 Ohm W/Mtg Bkt | 1 |
| ... | 27 | 248940 | Bracket,Mtg Stabilizer | 2 |
| ... | 28 | 173352 | Extrusion, Rubber Clamp/Bulb | ft |
| ... | 29 | 249772 | Stabilizer | 2 |
| ... | 30 | 254089 | Angle, Mounting Panel | 1 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.




Figure 12-2. Main Assembly – Part 2

907 520-7

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|


Figure 12-2. Main Assembly – Part 2

| | | | | |
|-----|----|---------|--------------------------------------------------------------------|-----|
| ... | 1 | 201934 | Cover, Top | 1 |
| ... | 2 | 233088 | Label, Danger Using A Generator Indoors Can Kill | 1 |
| ... | 3 | 189052 | Grommet, Plastic Neck Filler Fuel | 1 |
| ... | 4 | 190198 | Cap, Tank Screw-on 3.500 In W/Vent W/Lanyard 8" | 1 |
| ... | 5 | 192041 | Label, Use Diesel Fuel Only | 1 |
| ... | 6 | 105734 | Pipe, Muffler Extension Elbow 1.750 Od | 1 |
| ... | 7 | 201851 | Cover, Radiator Access | 1 |
| ... | 8 | 191354 | Support, Cover | 1 |
| ... | 9 | 201592 | Pipe, Exhaust | 1 |
| ... | 10 | 010875 | Clamp, Muffler 2.000 Dia U Pld | 1 |
| ... | 11 | 191817 | Baffle, Air | 1 |
| ... | 12 | 251365 | Engine, Deutz Dsl Elec D2011I04i (Consisting Of) | 1 |
| ... | | *067265 | Filter, Oil (Engine) | 1 |
| ... | | *192744 | Filter, Fuel Spin-On | 1 |
| ... | | *066217 | Filter, Fuel Secondary | 1 |
| ... | | *195745 | Switch, Oil Pressure | 1 |
| ... | | *195746 | Sender, Coolant | 1 |
| ... | | *246988 | Kit, Filter D2011I04i Engine (Includes Air, Fuel, And Oil Filters) | 1 |
| ... | | 207847 | Heater, Block Engine 120 Volt 300 Watt | 1 |
| ... | 13 | 219229 | Bracket, Support Solenoid | 1 |
| ... | 14 | 252636 | Guard, Engine Pulley | 1 |
| ... | 15 | *216959 | Blower Belt | 1 |
| ... | 16 | 174064 | Idle, Solenoid Assy | 1 |
| ... | 17 | 199849 | Screw, 625-11 X 4.00hexhd Pln Gr 5 Pld | 4 |
| ... | 18 | 071731 | Washer, Flat .656 Id X 2.250 Od X .187t Stl Pld | 4 |
| ... | 19 | 071890 | Retainer, Mount Eng/Gen | 4 |
| ... | 20 | 083476 | Mount, Eng/Gen Nprn .875 Id X 2.500 Od X 2.000 | 4 |
| ... | 21 | 135205 | Nut, 625-11 .94hex .76h Stl Pld Elastic Stop Nut | 4 |
| ... | 22 | 071730 | Tubing, Stl .875 Od X 12ga Wall X 2.500 | 4 |
| ... | 23 | 191812 | Bracket, Mtg Engine Rh | 1 |
| ... | 24 | 199507 | Hose, Oil Drain Assy 20 In (Consisting Of) | 1 |
| ... | | 165271 | Valve, Oil Drain 3/8-18nptf | 1 |
| ... | | 176529 | Fitting, Hose Brs Barbed Fem 1/2tbg X 3/8npt | 1 |
| ... | | 113854 | Hose, Sae .500 Id X .780 Od Xc Oil (Order By Ft) | 2ft |
| ... | 25 | 176528 | Fitting, Hose Brs Barbed Elbow Fem 1/2 Tbg X 1/2 Npt | 1 |
| ... | 26 | 173336 | Fitting, Adapter Oil Drain | 1 |
| ... | | | Washer, Oil Drain (Available Through Engine Manufacturer) | 1 |
| ... | 27 | | Generator see Figure 12-10 | |
| ... | 28 | 252571 | Hose, Air Intake | 1 |
| ... | 29 | 023313 | Clamp, Hose 1.312 - 3.500 Clp Dia | 2 |
| ... | 30 | 189764 | Air Cleaner, Intake | 1 |
| ... | 31 | 189763 | Bracket, Mtg Air Cleaner | 1 |
| ... | 32 | 252492 | Box, Air Intake | 1 |
| ... | 33 | 252193 | Upright, Rear | 1 |
| ... | 34 | +252350 | Cover, Battery And Air Filter Access | 1 |
| ... | 35 | 168385 | Label, Warning Battery Explosion Can Blind | 1 |
| ... | 36 | 225120 | Label, Warning Moving Parts Can Cause Injury | 1 |
| ... | 37 | 211370 | Latch, Door | 2 |
| ... | 38 | 189975 | Hinge, Door Access 180deg | 2 |
| ... | 39 | +215252 | Guard, Belt | 1 |
| ... | 40 | 225120 | Label, Warning Moving Parts Can Cause Injury | 1 |
| ... | 41 | 206297 | Base, Fuel Filter Assy | 1 |
| ... | 42 | 145282 | Fitting, Hose Brs Barbed Elbow M 5/16tbg X 1/4npt | 2 |
| ... | 43 | 173909 | Hose, Sae .312 Id X .560 Od X 24.000 | 1 |
| ... | 44 | 225447 | Hose, Sae .312 Id X .560 Od X 32.000 | 1 |
| ... | 45 | *192744 | Filter, Fuel Spin-On | 1 |
| ... | 46 | 190992 | Keeper, Latch Engine Access Door | 1 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|--------------------------------------------------------|------------|----------|---------------------------------------------------------------|----------|
| Figure 12-2. Main Assembly – Part 2 (Continued) | | | | |
| ... 47 | | 252810 | .. Channel, Stiffener Engine Access | 1 |
| ... 48 | | 237352 | .. Label, Maintenance Big Blue Deutz Series Ce | 1 |
| ... 49 | | +252812 | .. Door, Engine Access | 1 |
| ... 50 | | 225120 | .. Label, Warning Moving Parts Can Cause Injury | |
| ... 51 | | 245362 | .. Latch, Paddle Series 20 (Black) | 1 |
| ... 52 | | 252813 | .. Panel, Rocker | 1 |
| ... 53 | | 189975 | .. Hinge, Door Access 180deg | 2 |
| ... 54 | | 208141 | .. Stop, Door | 2 |
| ... 55 | | 217698 | .. Label, Help Codes | 1 |
| ... 56 | | 238650 | .. Label, Hour/Fuel Meter Usage | 1 |
| ... 57 | | 250400 | .. Panel, Generator Rh | 1 |
| ... 58 | | 190896 | .. Battery, Stor 12v 660 Crk 110 Rsv Gp 24 Low Mainte | 1 |
| ... 59 | | 201006 | .. Bolt, J Stl .312-18 X 8.500 Pld | 2 |
| ... 60 | | 203430 | .. Bracket, Battery Holddown | 1 |
| ... 61 | | 190207 | .. Cable, Bat Pos 45 In Lg No. 1 Awg W/Clamp And .406rng | 1 |
| ... 62 | | 108081 | .. Terminal Protector, Battery Post Mtg | 2 |
| ... 63 | | 190206 | .. Cable, Bat Neg 42 In Lg No. 2 Awg W/Clamp And .375rng | 1 |
| ... 64 | | 191446 | .. Extrusion, Rubber W/Adhesive 1.000 X 1.000 D (Order By Ft) | 6ft |
| ... 65 | | 218087 | .. Tank, Fuel (Consisting Of) | 1 |
| ... 66 | | 181572 | .. Bushing, Tank Fuel | 1 |
| ... 67 | | 189908 | .. Valve, Drain Fuel 180deg | 1 |
| ... 68 | | 189912 | .. Fitting, Stl Barbed Elbow W/.047 In Orf Zinc Pld | 1 |
| ... 69 | | 190142 | .. Sender, Fuel Gauge 9.7500 Deep Tank | 1 |
| ... 70 | | 189909 | .. Fitting, Stand Pipe Hose .250 X 9.260 Lg 90deg Zinc | 1 |
| ... 71 | | 189910 | .. Fitting, Stand Pipe Hose .3125 X 9.260 Lg 90deg Zinc | 1 |
| ... 72 | | 124253 | .. Bushing, Tank Fuel | 4 |
| ... 73 | | 189913 | .. Fitting, Stl Barbed Elbow Zinc Pld | 1 |
| ... 74 | | 191809 | .. Bracket, Mtg Engine Lh | 1 |
| ... 75 | | 191577 | .. Guard, Starter Deutz | 1 |
| ... 76 | | 200730 | .. Manifold, Exhaust Muffler F4I1011 Deutz | 1 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.



260 008

Figure 12-3. Control Box Assembly

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-3. Control Box Assembly (Figure 12-1 Item 21)

| | | | | | |
|-----|----|--------------|-----------------|------------------------------------------------------------|---|
| ... | 1 | 201077 | Control Box, Lh | 1 | |
| ... | 2 | 249708 | Control Box, Rh | 1 | |
| ... | 3 | TE2, TE3 | 190210 | Block, Term 5-3-3 | 2 |
| ... | 4 | CR4, CR24 | 090104 | Relay, Encl 12vdc Spst 30a/15vdc 5 Pin Flange Mtg | 2 |
| ... | 5 | CB14 | 205927 | Circuit Breaker, Auto Reset 12vdc 12 Amp | 1 |
| ... | 6 | CB10 | 190374 | Circuit Breaker, Auto Reset 12vdc 40a | 1 |
| ... | 7 | CR8 | 197325 | Relay, Encl 12vdc Spst 70a 4 Pin Flange Mtg | 1 |
| ... | 8 | CR5 | 223710 | Relay, Encl 12vdc Dpst-No 25a 6pin Flange | 1 |
| ... | 9 | SR1-4, 6, 23 | 035704 | Rectifier, Integ 40a 800v | 6 |
| ... | 10 | | 201079 | Cover, Control Box | 1 |
| ... | 11 | | 177136 | Clamp, Capacitor 1.375dia | 1 |
| ... | 12 | C6 | 087110 | Capacitor, Elctlt 240uf 200vdc | 1 |
| ... | 13 | CB2,3,4 | 139266 | Supplementary Protector, Man Reset 1p 15a 250vac | 3 |
| ... | 14 | S5 | 028111 | Switch, Tgl Dpst 20a 250v Spd Term | 1 |
| ... | 15 | | 202209 | Spacer, Nylon .805 Od X .510 Id X .220 Lg | 1 |
| ... | 16 | | 256852 | Holder, Fuse Mintr W/10a Slo-Blo Fuse | 2 |
| ... | | F1, F2 | *085874 | Fuse, Mintr Cer Slo-Blo 10a 250v | 2 |
| ... | 17 | | 021385 | Boot, Toggle Switch Lever | 1 |
| ... | | | 258549 | Label, Vrd On/Off | 1 |
| ... | | CR1 | 252053 | Relay, Encl 12vdc Spst 35a/14vdc 5 Pin (In wiring harness) | 1 |

*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.




Figure 12-4. Panel, Front Engine & Weld Controls

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|


Figure 12-4. Panel, Front Engine & Weld Controls

| | | | | |
|-----|----|----------------------|--------------------------------------------------------|---|
| ... | 1 | 218764 | Knob, Pointer 1.625 Dia | 2 |
| ... | 2 | 207080 | Knob, Pointer 1.125 Dia | 4 |
| ... | 3 | OIL 217083 | Gauge, Pressure Oil 0-100 Psi | 1 |
| ... | | 193230 | Sender, Pressure Oil 0- 100 Psi | 1 |
| ... | 4 | FUEL/HM 232113 | Gauge, Fuel Elec/Hour Meter | 1 |
| ... | 5 | | Nameplate, Screened (Order By Model And Serial Number) | 1 |
| ... | 6 | 248893 | Panel, Engine/Weld Control | 1 |
| ... | 7 | R1, R21 246961 | Switch, Rotary 8 Posn 1p 200ma 28vdc W/Resistors | 2 |
| ... | 8 | R2, 5, 22, 25 193118 | Pot,Cp Flat 1t 2. W 1k Ohm Linear | 4 |
| ... | 9 | PC2, PC22 251527 | Circuit Card Assy, Display W/Program | 2 |
| ... | 10 | 248914 | Enclosure, Circuit Card Assy | 2 |
| ... | 11 | 134201 | Stand-off Support, Pc Card .312/.375w/Post&Lock .43 | 8 |
| ... | 12 | PC5, PC25 242263 | Circuit Card Assy, Connector/Receptacle | 2 |
| ... | 13 | CB9, CB29 083432 | Supplementary Pro, Man Reset 1p 10a 250vac Frict | 2 |
| ... | 14 | S1 217680 | Switch, Ignition 4 Position W/Out Handle | 1 |
| ... | 15 | TEMP 217084 | Gauge, Coolant Temp 0- 300 Deg F | 1 |
| ... | | 197798 | Sender, Coolant Temp 300 Deg F M16 X 1.5 | 1 |
| ... | 16 | 207073 | Lever,Ignition Switch | 1 |
| ... | | 201244 | Washer,Tooth.728idx1.166odx.050t Stl Pld Int.6881 | |
| ... | 17 | 190323 | Boot,Circuit Breaker Clear Hex Nut | 2 |
| ... | 18 | 170391 | Conn,Circ Ms Protective Cap Size 20 Nylon | 2 |
| ... | 19 | S2 ♦021467 | Switch, Tgl Spst 3a 250v Off-none-(On) Spd Term | 1 |
| ... | 20 | ♦021385 | Boot, Toggle Switch Lever | 1 |

♦OPTIONAL

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.



907 520-6B

Figure 12-5. Panel, Weld Output


| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-5. Panel, Weld Output

| | | | | |
|-------|---------------|---------------|----------------------------------------------------|---|
| ... | 1 | 186621 | .. Boot, Generic Output Stud | 4 |
| ... | 2 | ◆010647 | .. Pin, Spring | 1 |
| ... | 3 | ◆111785 | .. Handle, Switch | 1 |
| ... | 4 | | .. Nameplate (Order By Model & Serial No.) | 1 |
| ... | 5 | 248895 | .. Panel, Mtg Terminal Power Output | 1 |
| ... | 6 | 241432 | .. Terminal, Pwr Output Red | 2 |
| ... | 7 | 241433 | .. Terminal, Pwr Output Blk | 2 |
| | C4, 5, 24, 25 | 128750 | .. Capacitor, Cer Disc .1 Uf 500 Vdc W/Terms | 4 |
| ... | 8 | S3 .. ◆249353 | .. Switch, Paralleling | 1 |

◆OPTIONAL

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



907 520-6C


Figure 12-6. Panel, Auxiliary Power North America

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-6. Panel, Auxiliary Power North America

| | | | | |
|-----|----|----------|-----------------------------------------------------|---|
| ... | 1 | 214927 | .. Boot,Circuit Breaker 1 Pole | 1 |
| ... | 2 | 209056 | .. Cover,Receptacle W/Gasket | 7 |
| ... | 3 | | .. Nameplate (Order By Model & Serial No.) | 1 |
| ... | 4 | RC5 | .. Rcpt,Str 3p4w 50a 125/250v Flush Mtg *14-50 | 1 |
| ... | 5 | 190323 | .. Boot,Circuit Breaker Clear Hex Nut | 1 |
| ... | 6 | CB6 | .. Supplementary Protector,Man Reset 2p 20a 250vac | 1 |
| ... | 7 | 248894 | .. Panel,Aux Power | 1 |
| ... | 8 | 025248 | .. Stand-off,Insul .250-20 X 1.250 Lg X .437 Thd | 1 |
| ... | 9 | GFCI1, 2 | .. RCPT, str dx grd 2P3W 20A 125V *5-20r GFI | 2 |
| ... | 10 | CB1 | .. Supplementary Protector,Man Reset 3p 50a 250vac | 1 |
| ... | 11 | RC4 | .. Rcpt,Str 3p4w 50a 250v Flush Mtg | 1 |
| ... | 12 | CB7, CB8 | .. Supplementary Pro, Man Reset 1p 20a 250vac Frict | 2 |
| ... | 13 | RC1, RC2 | .. Receptacle, Tw Lk Grd 2p3w 30a 250v L6-30r | 2 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



907 520-6D


Figure 12-7. Panel, Auxiliary Power Export

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-7. Panel, Auxiliary Power Export

| | | | | |
|-----|----|--------------------|-----------------------------------------------------|---|
| ... | 1 | 209056 | .. Cover, Receptacle W/Gasket | 4 |
| ... | 2 | | .. Nameplate (Order By Model & Serial No.) | 1 |
| ... | 3 | 250935 | .. Panel, Aux Power (Export) | 1 |
| ... | 4 | CB7, CB8 .. 093996 | .. Supplementary Pro, Man Reset 1p 20a 250vac Frict | 2 |
| ... | 5 | GFCI1,2 .. 246865 | .. Rcpt, Str Dx Grd 2p3w 20a 125v *5-20r Gfi | 2 |
| ... | 6 | CB1 .. 214926 | .. Supplementary Protector, Man Reset 3p 50a 250vac | 1 |
| ... | 7 | ELCB1 .. 222991 | .. Circuit Breaker, Elcb 16a 220v 0.030a Trip | 1 |
| ... | 8 | CB5 .. 117501 | .. Supplementary Protector, Man Reset 1p 40a 250vac | 1 |
| ... | 9 | 025248 | .. Stand-off, Insul .250-20 X 1.250 Lg X .437 Thd | 1 |
| ... | 10 | RC3, RC4 .. 176355 | .. Rcpt, Str 2p3w 16a 220v Flange Mtg | 2 |
| ... | 11 | RC1, RC2 .. 173555 | .. Rcpt, Str 2p3w 16a 130v Flange Mtg | 2 |
| ... | 12 | 190323 | .. Boot, Circuit Breaker Clear Hex Nut | 3 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



907 520-6E


Figure 12-8. Panel, Auxiliary Power Export Deluxe

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-8. Panel, Auxiliary Power Export Deluxe

| | | | | |
|-----|----|--------------------|-----------------------------------------------------|---|
| ... | 1 | 209056 | .. Cover, Receptacle W/Gasket | 3 |
| ... | 2 | | .. Nameplate (Order By Model & Serial No.) | 1 |
| ... | 3 | 250935 | .. Panel, Aux Power (Export) | 1 |
| ... | 4 | CB7, CB8 .. 093996 | .. Supplementary Pro, Man Reset 1p 20a 250vac Frict | 2 |
| ... | 5 | GFCI1,2 .. 246865 | .. Rcpt, Str Dx Grd 2p3w 20a 125v *5-20r Gfi | 2 |
| ... | 6 | 214927 | .. Boot, Circuit Breaker 1 Pole | 1 |
| ... | 7 | CB1 .. 254884 | .. Supplementary Protector, Man Reset 3p 30a 480vac | 1 |
| ... | 8 | ELCB1 .. 222991 | .. Circuit Breaker, Elcb 16a 220v 0.030a Trip | 1 |
| ... | 9 | CB5 .. 117501 | .. Supplementary Protector, Man Reset 1p 40a 250vac | 1 |
| ... | 10 | 025248 | .. Stand-off, Insul .250-20 X 1.250 Lg X .437 Thd | 1 |
| ... | 11 | RC5 .. 251972 | .. Rcpt, Str 4p5w 32a 400v 3ph Flange Mtg | 1 |
| ... | 12 | RC3, RC4 .. 176355 | .. Rcpt, Str 2p3w 16a 220v Flange Mtg | 2 |
| ... | 13 | RC1, RC2 .. 173555 | .. Rcpt, Str 2p3w 16a 130v Flange Mtg | 2 |
| ... | 14 | 190323 | .. Boot, Circuit Breaker Clear Hex Nut | 3 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



907 520-9

Figure 12-9. Weld Control Assembly


| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-9. Weld Control Assembly (Figure 12-1 Item 11)

| | | | | |
|-----|----|--------------------|-----------------------------------------------------------|---|
| ... | 1 | 250348 | .. Bus Bar, Negative | 2 |
| ... | 2 | 250323 | .. Insulator, Rectifier | 2 |
| ... | 3 | 250350 | .. Bus Bar, Positive | 2 |
| ... | 4 | 250343 | .. Bracket, Mtg Vault | 1 |
| ... | 5 | PC1, PC21 . 258544 | .. Module, Main Control/Igbt Gating | 2 |
| ... | 6 | 250347 | .. Bracket, Mtg Rectifier | 1 |
| ... | 7 | SR6, SR26 . 248933 | .. Rectifier, Si 3ph 300 Amp 600 Piv | 2 |
| ... | 8 | HD1, HD21 . 168829 | .. Transducer, Current 1000a Module Max Open Loop | 2 |
| ... | 9 | 239547 | .. Washer, Flat Nylon .516 Id X 1.250 Od X .062 Thk | 4 |
| ... | 10 | C3, C23 . 246841 | .. Capacitor, Elctlt 35000 Uf 100 Vdc Can 3.00 Dia | 4 |
| ... | 11 | 247093 | .. Stand-off, Conductive Bus | 4 |
| ... | 12 | 245378 | .. Buss Bar, Ac | 2 |
| ... | 13 | 250346 | .. Bracket, Mtg Capacitors | 2 |
| ... | 14 | 247407 | .. Heat Sink Assy, Igbt | 2 |

To Maintain The Factory Original Performance Of Your Equipment, Use Only Manufacturer'S Suggested Replacement Parts. Model And Serial Number Required When Ordering Parts From Your Local Distributor.

☞ Hardware is common and not available unless listed.



802 404-C

Figure 12-10. Generator

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-10. Generator (Figure 12-2 Item 27)

| | | | | |
|-----|----|--------------|--------------------------------------------------------------|----|
| ... | 1 | 132053 | .. Screw, 375-16 X 1.50hexhd Pln Gr 5pld | 6 |
| ... | 2 | 183387 | .. Washer, Conical Spring .406 Id X .875 Od Pltd | 6 |
| ... | 3 | 252572 | .. Endbell, Gen | 1 |
| ... | 4 | 143220 | .. O-Ring, 2.859 Id X .139cs | 1 |
| ... | 5 | 250990 | .. Stator, Exciter/Aux Pwr | 1 |
| ... | 6 | 249645 | .. Stator, Weld/Power Assy Complete (Full Kva North America) | 1 |
| ... | 6 | +252585 | .. Stator, Weld/Power Assy Complete (Export Models) | 1 |
| ... | | 191579 | .. Cover, Starter Hole Perkins/Continental | 1 |
| ... | | 191580 | .. Cover, Starter Hole Deutz | 1 |
| ... | 7 | 225120 | .. Label, Warning Moving Parts Can Cause Injury | 2 |
| ... | 8 | 190197 | .. Guard, Generator Wire Mesh | 1 |
| ... | 9 | 172674 | .. Spring, Ext .240 Od X .041 Wire X 3.500pld | 2 |
| ... | 10 | 039207 | .. Baffle, Air | 1 |
| ... | 11 | ROTOR 251855 | .. Rotor, Generator Segmented Assy (Includes) | 1 |
| ... | 12 | 251856 | .. Rotor, Generator (Includes) | 1 |
| ... | 13 | 024617 | .. Ring, Rtng Ext 1.375 Shaft X .050 Thk | 1 |
| ... | 14 | 053390 | .. Bearing, Ball Rdl Sgl Row 1.370 X 2.830 X .6 | 1 |
| ... | | | .. Hub, Drive (Not Sold Separately) | 1 |
| ... | | 210447 | .. Fan, Rotor Assy Generator (Segmented) (Includes) | 1 |
| ... | 15 | 210332 | .. Plate, Flex Hubmount | 1 |
| ... | 16 | 206242 | .. Fan, Rotor Segmented Assy Gen | 4 |
| ... | 17 | 049026 | .. Screw, M10-1.5x 25 Hex Hd-Pln 8.8 Pln | 10 |
| ... | 18 | 083883 | .. Washer, Lock .402idx0.709odx.087t Stl Split10mm | 10 |
| ... | 19 | 080389 | .. Screw, 312-18x1.00 Hexwhd.66d Stl Pld Slffmg Tap-Rw | 8 |
| ... | 20 | 083883 | .. Washer, Lock .402idx0.709odx.087t Stl Split10mm | 10 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-10. Generator (Continued)

| | | | | |
|--------|---------|----|------------------------------------------------------|---|
| ... 21 | 049026 | .. | Screw, M10-1.5x 25 Hex Hd-Pln 8.8 Pln | 4 |
| ... 22 | 172555 | .. | Screw, M10-1.5 X 50hexhd Pln 8.8pld | 6 |
| ... 23 | 602159 | .. | Screw, .312-18x .75 Hexwhd.66d Stl Pld Slffmg Tap-Rw | 6 |
| ... 24 | *190823 | .. | Brush, Contact | 3 |
| ... 25 | 208469 | .. | Clip, Spring | 3 |
| ... 26 | 189142 | .. | Brushholder, Generator | 1 |
| ... 27 | 139341 | .. | Washer, Exciter | 4 |
| ... 28 | 602211 | .. | Washer, Lock .318idx0.586odx.078t Stl Pld Split.312 | 4 |
| ... 29 | 604950 | .. | Screw, 312-18x2.00 Hex Hd-pln Gr5 Pld | 4 |
| | 602211 | .. | Washer, Lock .318 Id X 0.586 | 2 |
| | 604534 | .. | Screw, 312-18x1.25 Hex Hd-pln Gr5 Pld | 2 |
| | 602242 | .. | Washer, Flat .375idx0.875odx.083t Stl Pld Blk | 2 |

+ When ordering a component originally displaying a precautionary label, the label should also be ordered.

*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Some wiring harness components (switches, relays, supplementary protectors) are also referenced elsewhere in this parts list. Purchase components separately or as part of the associated wiring harness.

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|-------------------------|-----------------------------------|-----------|-----------------------------------------------------------|----------|
| Wiring Harnesses | | | | |
| | | 251608 .. | Harness, Engine 2011 NA (Includes) | 1 |
| | PLG4 | 214932 .. | Conn, Rect Univ 039 8p/S 2row Plug Cable Lkg Seal | 1 |
| | PLG13-PLG14 | 150316 .. | Conn, Rect Univ 039 6p/S 3row Plug Cable Lkg | 2 |
| | at S1 | 177859 .. | Conn, Body 5 Terminal | 1 |
| | PLG16-PLG17 | 148850 .. | Socket, Relay 5 Pin | 2 |
| | PLG12 | 173916 .. | Conn, Rect Housing 10 Circuit | 1 |
| | | 214933 .. | Seal, Wire Univ 039 | 14 |
| | | 214934 .. | Seal, Plug Univ 039 | 6 |
| | | 260009 .. | Harness, Weld Control (Includes) | 1 |
| | PLG6,PLG26 | 193184 .. | Conn, Rect Cinch 30 Pin | 2 |
| | PLG7,11,27,211 | 193183 .. | Conn, Rect Cinch 18 Pin | 4 |
| | PLG5,10,20,25,210,220113751 | | Conn, Rect Mini 045 8skt 2row Plug Cable Lkg | 6 |
| | PLG2,9,22,29 | 150316 .. | Conn, Rect Univ 039 6p/S 3row Plug Cable Lkg | 4 |
| | RC3,RC23 | 155129 .. | Conn, Rect Univ 039 6p/S 3row Rcpt Cable/Panel Lkg | 2 |
| | PLG8,PLG28 | 231708 .. | Conn, Rect Univ 039 10p/S 2row Plug Cable Lkg Seal | 2 |
| | RC99 | 158466 .. | Conn, Rect Univ 084 12p/S 3row Rcpt Cable/Panel Lkg | 1 |
| | RC98 | 135133 .. | Conn, Rect Univ 084 9p/S 3row Rcpt Cable/Panel Lkg | 1 |
| | | 250974 .. | Cable, Lem | 2 |
| | | 196602 .. | Plug, Cavity 18,30 Position Cinch Connector | 38 |
| | | 214933 .. | Seal, Wire Univ 039 | 64 |
| | | 214934 .. | Seal, Plug Univ 039 | 40 |

TRUE BLUE[®]

WARRANTY

Effective January 1, 2013

(Equipment with a serial number preface of MD or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

Warranty Questions?

Call
1-800-4-A-MILLER
for your local
Miller distributor.

Your distributor also gives
you ...

Service

You always get the fast,
reliable response you
need. Most replacement
parts can be in your
hands in 24 hours.

Support

Need fast answers to the
tough welding questions?
Contact your distributor.
The expertise of the
distributor and Miller is
there to help you, every
step of the way.

LIMITED WARRANTY – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the delivery date of the equipment to the original end-user purchaser, and not to exceed one year after the equipment is shipped to a North American distributor or eighteen months after the equipment is shipped to an International distributor.

1. 5 Years Parts — 3 Years Labor
 - * Original Main Power Rectifiers Only to Include SCRs, Diodes, and Discrete Rectifier Modules
2. 3 Years — Parts and Labor
 - * Auto-Darkening Helmet Lenses (Except Classic Series) (No Labor)
 - * Engine Driven Welding Generators
(NOTE: Engines are Warranted Separately by the Engine Manufacturer.)
 - * Inverter Power Sources (Unless Otherwise Stated)
 - * Oxy-Fuel Cutting Torches (No Labor)
 - * Plasma Arc Cutting Power Sources
 - * Process Controllers
 - * Semi-Automatic and Automatic Wire Feeders
 - * Smith Series 30 Flowgauge, Flowmeter, and Pressure Regulators (No Labor)
 - * Transformer/Rectifier Power Sources
 - * Water Coolant Systems (Integrated)
3. 2 Years — Parts and Labor
 - * Auto-Darkening Helmet Lenses – Classic Series Only (No Labor)
 - * Fume Extractors – Filtair 400 and Industrial Collector Series
4. 1 Year — Parts and Labor Unless Specified
 - * Automatic Motion Devices
 - * CoolBelt and CoolBand Blower Unit (No Labor)
 - * External Monitoring Equipment and Sensors
 - * Field Options
(NOTE: Field options are covered for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
 - * Flowgauge and Flowmeter Regulators (No Labor)
 - * RFCS Foot Controls (Except RFCS-RJ45)
 - * Fume Extractors – Filtair 130, MWX and SWX Series
 - * HF Units
 - * ICE/XT Plasma Cutting Torches (No Labor)
 - * Induction Heating Power Sources, Coolers
(NOTE: Digital Recorders are Warranted Separately by the Manufacturer.)
 - * Load Banks
 - * Motor Driven Guns (except Spoolmate Spoolguns)
 - * PAPR Blower Unit (No Labor)
 - * Positioners and Controllers
 - * Racks
 - * Running Gear/Trailers
 - * Spot Welders
 - * Subarc Wire Drive Assemblies
 - * Water Coolant Systems (Non-Integrated)
 - * Weldcraft-Branded TIG Torches (No Labor)
 - * Wireless Remote Foot/Hand Controls and Receivers
 - * Work Stations/Weld Tables (No Labor)

5. 6 Months — Parts
 - * Batteries
 - * Bernard Guns (No Labor)
 - * Tregaskiss Guns (No Labor)
6. 90 Days — Parts
 - * Accessory (Kits)
 - * Canvas Covers
 - * Induction Heating Coils and Blankets, Cables, and Non-Electronic Controls
 - * M-Guns
 - * MIG Guns and Subarc (SAW) Guns
 - * Remote Controls and RFCS-RJ45
 - * Replacement Parts (No labor)
 - * Roughneck Guns
 - * Spoolmate Spoolguns

Miller's True Blue[®] Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, relays, work station table tops and welding curtains, or parts that fail due to normal wear. (Exception: brushes and relays are covered on all engine-driven products.)**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.





Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

City

State

Zip



For Service

Contact a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables

Options and Accessories

Personal Safety Equipment

Service and Repair

Replacement Parts

Training (Schools, Videos, Books)

Technical Manuals (Servicing Information and Parts)

Circuit Diagrams

Welding Process Handbooks

To locate a Distributor or Service Agency visit www.millerwelds.com or call 1-800-4-A-Miller

Contact the Delivering Carrier to:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

Miller Electric Mfg. Co.

An Illinois Tool Works Company
1635 West Spencer Street
Appleton, WI 54914 USA

International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended
USA & Canada FAX: 920-735-4134
International FAX: 920-735-4125

For International Locations Visit
www.MillerWelds.com

